

Toughpower 700W / 800W



Copyright © 2008 Thermaltake Technology Co., Ltd. All Rights Reserved. All trademarks are the property of their respective owners. Reproduction in whole or in part without written permission is prohibited.





User Manual
Gebrauchsanleitung
Gui d'deutilisation
Manual del usuario
Manuale d'uso
使用手冊
用户手册
ユーザーマニュアル
Руководство пользователя

Kullaným klavuzu

♦ Table of contents **♦**

01. Warnings & Caution (⊃1
02. Components Check	02
03. Power Connector Introduction (03
04. Installation Steps (04
05. Product Features (05
06. Output Specification	06
07. Total Protection (06
08. EMI & SAFETY	07
09. Environments (07
10. Trouble Shooting (07





- 1. Do not unplug the AC power cord when the power supply is in use. Doing so may cause damage to your components.
- 2. Do not place the power supply in a high humidity and/or temperature environment.
- 3. High voltages exist in the power supply. Do not open the power supply case unless you are an authorized service technician or electrician. Doing so will void the warranty.
- 4. PSU should be powered by the source indicated on the rating label.
- 5. All warrantees and guarantees will be voided, if failure to comply with any of the warnings and cautions covered in this manual.





2. Components Check






- Toughpower 80Plus (Silver) 700W / 800W power supply unit
- User manual
- AC power cord
- Mounting screw x 4
- Silicone rubber mounting gasket x 1
- Cable strap x 4





3. Power Connector Introduction



8	Connector Type	Connectors & Cable length
	20+4pin	1 x 20+4pin Main connector (500mm)
	ATX 12V 4pin	1 x ATX 12V 4pin connector (500mm)
MODELS	EPS 12V 8pin	1 x EPS 12V 8pin connector (500mm)
700W 800W	Molex & FDD	2 x Peripheral & 1 x FDD connectors (500mm + 150mm + 150mm) 3 x Peripheral connectors (500mm + 150mm + 150mm)
	SATA	3 x S-ATA connectors (500mm + 150mm + 150mm) 3 x S-ATA connectors (500mm + 150mm + 150mm)
	PCI-E 8/6pin	1 x 8/6pin PCI-E connectors (500mm + 150mm)
0	. э. 2 б/орш	1 x 8/6pin PCI-E connectors (500mm + 150mm)

Toughpower[™] 700W / 800W

4. Installation Steps



Note: Make sure that your system is turned off and unplugged.

Disconnect the AC power cord from your old power supply.



- 1. Open your computer case; please refer to the direction in your case manual.
- 2. Install the PSU into the case with the four screws provided.
- 3. Connect the 24 pin Main Power Connector to your motherboard and peripheral. If your motherboard uses a 20-pin connector, detach the 4-pin attachment on the 24-pin connector.

 Note: The detachable 4-pin section cannot be used in place of a 4-pin +12V connector.
- 4. Connect the 8-pin or 4-pin connector for the CPUs.
- 5. Connect other peripheral power connectors to devices such as hard drives, optical drives, etc.
- 6. Close your computer case and connect the AC power cord to the power supply AC inlet.





5. Product Features



6. Output Specification

	INPUT VOLT	INPUT VOLTAGE: 100V-240V~, FREQUENCY: 50HZ-60HZ						
MODEL	Voltage	+3.3V	+5V	+12V1	+12V2	-12V	+5Vsb	TOTAL POWER
70014/	MAX Load	24A	30A	30A	35A	0.5A	3.5A	700\4
700W	Combined Wattage	170	W	672	2W	6W	17.5W	700W
800W	MAX Load	24A	30A	30A	40A	0.5A	3A	000147
	Combined Wattage	150)W	792	2W	6W	15W	800W

7. Total Protection

Over Voltage Protection W0295 (700W) / W0296 (800W)		
Voltage Source	Protection Point	
+3.3V	3.76V-4.8V	
+5V	5.6V-7V	
+12V	13.5V-16.5V	

Over Current Protection

W0295 (700W)		
Output Voltage	Max. over current limit	
+3.3V	35.0A	
+5V	40.0A	
+12V1 DC	40.0A	
+12V2 DC	45.0A	

W029	6 (800W)
Output Voltage	Max. over current limit
+3.3V	35.0A
+5V	40.0A
+12V1 DC	40.0A
+12V2 DC	55.0A

Short Circuit Protection

Activated when any DC rails short circuited.


	EMI Regulatory				
W0295 (700W) W0296 (800W)	W0295 (700W)	FCC Part 15 Subpart J, Class B 115 Vac operation			
	W0296 (800W)	CISPR 22 Class B 230 Vac operation			
	SAFETY Standards				
0	W0295 (700W) W0296 (800W)	UL, CUL, CE, FCC, BSMI and GOST certified.			

9. Environments

8. EMI & SAFETY

	Temperature Range		
	Operating	+10°C to +40°C	
	Storage	-10°C to +60°C	
ا ہا	Humidity		
0	Operating	5-95% RH, Non-condensing	
	Storage	5-95% RH, Non-condensing	

10. Trouble-Shooting



Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com