
Xerox DocuPrint 96/4635/180 IPS Master Index

**THE DOCUMENT COMPANY
XEROX**

Version 7.1
August 2000
721P88220

Xerox Corporation
Printing Systems Documentation and Education
701 South Aviation Boulevard, ESM1-058
El Segundo, CA 90245

©1997, 1998, 1999, 2000 by Xerox Corporation. All rights reserved.

Copyright protection claimed includes all forms and matters of copyrightable material and information now allowed by statutory or judicial law or hereinafter granted, including without limitation, material generated from the software programs which are displayed on the screen, such as icons, screen displays, looks, etc.

Printed in the United States of America.

Publication number: 721P88220

Xerox® and all Xerox products mentioned in this publication are trademarks of Xerox Corporation. Products and trademarks of other companies are also acknowledged.

Changes are periodically made to this document. Changes, technical inaccuracies, and typographic errors will be corrected in subsequent editions.

Numerics

1.25 MB Data Streaming, CMS 3-4
1/4-inch cartridge tape drive, IPG 2-6
10Mb/sec twisted pair standard, IPG 4-7
2.5 MB Data Streaming, CMS 3-4
3-pitch mode, IPG A-5, SOG A-5
4 mm cartridge tape
drive, IPG 5-9
ordering, IPG A-13, SOG A-13
4 mm cartridge tape drive, IPG 2-3
4mm cartridge tape drive, cleaning, PRM 6-7
50 Hz voltage requirements
Delta configurations, IPG 6-4
Wye configurations, IPG 6-4
60 Hz voltage requirements, IPG 6-2
8 power (X) Comparator with MICR grid, IPG A-14,
SOG 5-4, SOG A-14
8-pitch mode, IPG A-4, SOG A-4

A

ABA standards, IPG 1-7
access control, SOG 1-16
access requirements, delivery, IPG 6-24–IPG 6-28
ACT icon, SOG 4-5
Add a New Form Type window, CMS 4-36
Add button, CMS 1-21
Add Profile button, CMS 1-21
Administration pull-down menu, CMS 1-13
Administrator Mode, CMS 4-2
Advanced Customer Training (ACT), IPG B-3, PRM
7-2
Advanced Function Image and Graphics (AFIG),
SOG 1-1
AFIG (Advanced Function Image and Graphics), IPG
1-1
AFP environment, SOG 1-5
AFP1 printer definition, IPG D-2
AIX
parameters, IPG E-25–IPG E-27
AIX environment
channel-attaching to an RS/6000, IPG D-5
configuring InfoPrint Manager, IPG D-5, IPG E-26
configuring PSF/6000, IPG D-5, IPG E-26

amount symbols, SOG 5-3
ANSI specifications, IPG 1-7
applications, customer responsibility, IPG 4-3
Apply & Update button, CMS 1-21
Apply buttons, CMS 1-21
AS/400
parameters, IPG E-18–IPG E-24
ASCII, IPG 1-6
Ask for File Name window, CMS 1-21
Attention light, TRB 2-1
attention light, SOG 4-6
attributes
finishing, CMS 4-55
audible tones, SOG 4-15
Auxiliary On-Us field, SOG 5-3

B

back panel, Sun workstations, IPG 2-3, IPG 2-6–IPG
2-7
backing up configuration files, CMS 1-13, CMS 4-63
Backup Configuration Files window, CMS 4-64
Barr/AFD, IPG 8-2
base components, IPG 2-1–IPG 2-10
BCOCA (Bar code Object Content Architecture),
SOG 1-5
Billing Information, CMS 1-13
billing meter
reading, IPG 8-4
reporting, IPG 8-4
BIN command, SOG 1-11
Bin Group field, CMS 4-18
Bin Selection Mode pull-down menu, CMS 4-52
Bin Unload button, PRM 2-2, SOG 4-11
binding, IPG 1-6
bins, PRM 2-1–PRM 2-3
Bins display field, CMS 1-16
Brightness control thumbwheel, SOG 4-5
bus and tag
cabling, IPG 2-10
channel connection, IPG 1-2
bus and tag cable input, SOG 2-5
bus and tag cables, SOG 1-4
bus and tag option, CMS 3-3, CMS 3-4
buttons

CMS = Guide to Configuring and Managing the System

IPG = Installation Planning Guide

PRM = Guide to Performing Routine Maintenance

SOG = System Overview Guide

TRB = Troubleshooting Guide

- incremental spin, CMS 1-5
- IPS main window
 - Reset Now, CMS 1-22
 - Save, CMS 1-22
- PQA, CMS 4-19
- using, CMS 1-5
- bypass connectors, SOG 2-5
- bypass transport
 - description, IPG 3-6
 - dimensions, IPG 6-13
 - option, IPG 1-6, SOG 1-14
 - paper path, IPG 6-15, SOG 4-18
 - programmable, SOG 4-14
 - service access, IPG 6-14
 - specifications, IPG 6-12–IPG 6-16, IPG 6-31
- bypass transport, clearing paper jams, TRB 3-21–TRB 3-22

C

- cables
 - bus, IPG 2-10
 - IBM channel, IPG 7-2
 - locations, IPG 7-2
 - tag, IPG 2-10
- Cancel Job button, CMS 1-20
- carbonless paper, IPG A-3, SOG A-3
- cartridge tape
 - drive, IPG 2-3, IPG 2-6, IPG 5-9
 - ordering, IPG A-13, SOG A-13
- cartridge tape drive, SOG 2-4
- CD, removing, CMS 2-8
- CD-ROM drive, IPG 2-3, IPG 2-5, SOG 2-4
- central processing unit, IPG 2-2, IPG 2-5
- channel attachments, IPG D-1–IPG D-3, IPG D-6
- channel communications board, SOG 2-1
- channel interface, selecting, CMS 3-4
- Channel Mode pull-down menu, CMS 3-4
- Channel Options window, CMS 3-4
- channel-attached
 - cables, IPG 7-2
 - configuration, IPG 1-3
 - systems, IPG 2-10
- Check Performance Guarantee, SOG 5-2
- checking
 - feeder trays, PRM 1-1
 - high-capacity stacker (HCS) bins, PRM 2-2
 - purge trays, PRM 2-1
 - sample trays, PRM 2-1
- checklist
 - installation planning, IPG 4-4–IPG 4-6
 - supplies, IPG A-25–IPG A-26, SOG A-25–SOG A-26
- cleaning
 - 4mm cartridge tape drive, PRM 6-7
 - keyboard, PRM 6-1
 - mirror, PRM 6-3
 - monitor, PRM 6-1
 - Printer Controller exterior, PRM 6-1
 - reflective surfaces, PRM 6-1
 - sensors
 - Q1011, PRM 6-3
 - Q1106, PRM 6-5
 - Q1107, PRM 6-4
 - Q1164, PRM 6-6
 - Q1166, PRM 6-5
 - Q850, PRM 6-2
- cleaning supplies, IPG A-21, SOG A-22
- Clear button, SOG 4-5
- clearance space, IPG 6-7, IPG 6-20–IPG 6-23
- clearing
 - feeder trays, TRB 3-2–TRB 3-3
 - paper jams
 - bypass transport, TRB 3-21–TRB 3-22
 - steps, TRB 3-7
- CMC7 fonts, SOG 5-1
- CMC7 series, IPG 1-8
- communicating, host computer, CMS 2-5–CMS 2-6
- components
 - base, IPG 2-1–IPG 2-10
 - controller, IPG 2-1
 - printer, IPG 3-1–IPG 3-3, SOG 4-2–SOG 4-6
 - Printer Controller, SOG 2-1–SOG 2-5
 - printer controller, IPG 2-1–IPG 2-10
- conditioning paper, IPG A-10–IPG A-11, SOG A-10–SOG A-11
- configuration
 - changes requiring reboot, CMS 3-1
 - input specifying, CMS 4-28–CMS 4-47
 - options, IPG 3-6–IPG 3-8
 - output specifying, CMS 4-49–CMS 4-62
 - printer, IPG 3-4–IPG 3-5
- configuration files
 - backing up, CMS 1-13
 - backing up and restoring, CMS 4-63
 - restoring, CMS 1-13
- configuration files, version identifier, SOG 1-15
- Configuration pull-down menu, CMS 1-11, CMS 4-6–CMS 4-14
- connectivity boards, IPG 2-1, IPG 2-4, SOG 2-3
- conprt utility, CMS 4-23
- consumable supplies table, IPG A-15–IPG A-21, SOG A-15–SOG A-22
- Continue button, CMS 1-20, SOG 4-5
- Continue button, no response, TRB 6-1
- continuous form emulation, CMS 1-11

CMS = Guide to Configuring and Managing the System

IPG = Installation Planning Guide

PRM = Guide to Performing Routine Maintenance

SOG = System Overview Guide

TRB = Troubleshooting Guide

continuous form jobs, SOG 1-14
 control panel
 HCF feeder tray, SOG 4-9
 HCS bin, SOG 4-11
 Control Unit Configuration section, CMS 1-18
 Control Unit display, CMS 1-19
 Copy Subgroup level, SOG 1-11
 customer education, PRM 7-3
 customer responsibilities, IPG 4-2–IPG 4-3, IPG 8-2
 Customer Transfer Assist Blade, SOG 5-2

D

damaged printing, correcting, TRB 4-1
 dash symbol, SOG 5-3
 data cables, IPG 7-1
 Data Control Interface Module (DCIM2) card, IPG 2-1,
 IPG 2-4, SOG 2-3
 data streams, SOG 1-1, SOG 1-5
 data streams, interpolated, IPG 1-5
 debug level, CMS 1-12
 debug level, setting, CMS 4-24
 decurler lever, adjusting, TRB 3-24
 Default Trace File Name window, CMS 4-21
 definitions, *see* sample printer definitions
 Delete button, CMS 1-21
 delivery requirements, IPG 6-24–IPG 6-28
 Delivery Signal Duration field, CMS 4-61
 Delivery Signal Start Adjust field, CMS 4-61
 Delivery Signal Type field, CMS 4-61
 DELTA configurations, IPG 6-4
 developer, IPG A-12, IPG A-21, SOG A-12, SOG
 A-22
 devices, input enablement, IPG 6-20
 DFA, CMS 1-21, SOG 1-14, SOG 4-14
 DFA Profile pull-down menu, CMS 4-53
 DFA profiles, CMS 4-62
 Diagnostic Authorization, CMS 1-13
 Diagnostic Authorization string, entering, CMS 3-14
 diagnostic tools, IPG 1-8
 diagnostic tracing, CMS 1-12
 diagnostics
 entering authorization string, CMS 3-14
 Diagnostics pull-down menu, CMS 1-12, CMS 4-15
 dimension gauge, SOG 5-4
 dimensions
 bypass transport, IPG 6-13
 controller, IPG 5-9
 printers, IPG 6-7–IPG 6-11
 diskette, ejecting, CMS 2-8
 diskettes, IPG A-13, IPG A-21, SOG A-13, SOG A-22
 display monitor, IPG 2-3, IPG 5-9

Document Feeding and Finishing Architecture, *see*
 DFA
 documentation
 AIX, IPG E-27
 AS/400, IPG E-24
 IBM, IPG C-2
 IBM channel connections, IPG 7-2
 MVS references, IPG E-17
 OS/2, IPG E-35
 Xerox, IPG C-1
 double-byte fonts, SOG 1-14
 drives
 cartridge tape, IPG 2-3, IPG 2-6, IPG 5-9
 CD-ROM, IPG 2-3, IPG 2-5
 disk, IPG 2-2, IPG 2-5
 drives, cartridge tape, SOG 2-4
 dropdown lists, CMS 1-3
 dry ink
 adding, PRM 4-1–PRM 4-3
 stains, PRM 4-3
 toner, IPG A-12, IPG A-21, SOG A-12, SOG A-22
 waste bottle, IPG A-21, SOG A-22
 Dual Mode, CMS 3-16, IPG 1-6, SOG 1-1
 duplex
 maximum simplex, CMS 1-11
 mode, simplex page value, CMS 4-8
 printing, selecting, CMS 4-30
 duplex, simplex flexibility, SOG 1-12

E

E13B fonts, SOG 5-1
 E13B series, IPG 1-8
 Edit the Media Defaults window, CMS 4-39
 education, customer, PRM 7-3
 electrical specifications, IPG 5-1–IPG 5-2, IPG 6-1–
 IPG 6-5
 End of Set field, CMS 1-17
 Enhanced Diagnostics option, CMS 1-13
 environmental requirements, IPG 6-6
 error condition, restarting printer, TRB 6-3
 Ethernet, CMS 2-5, CMS 3-5, IPG 2-1, IPG 2-4, SOG
 2-3
 configurations using, IPG 1-2
 requirements, IPG 4-7
 extraction color, CMS 1-11

F

Fault icon, SOG 4-5
 Fault List
 icon, TRB 2-1, TRB 6-1
 screen, TRB 2-1–TRB 2-2

CMS = Guide to Configuring and Managing the System
IPG = Installation Planning Guide
PRM = Guide to Performing Routine Maintenance
SOG = System Overview Guide
TRB = Troubleshooting Guide

Fault List icon, SOG 4-4
 faults, masking, TRB 2-1–TRB 2-2
 features
 600 dpi resolution, IPG 1-5
 advanced paper handling, IPG 1-4
 bypass transport option, IPG 1-6
 input trays, IPG 1-4
 output bins, IPG 1-6
 roll feeder, IPG 1-4
 feed belt, cleaning, TRB 3-4–TRB 3-5
 feeder trays, IPG 1-4, PRM 1-1–PRM 1-9, SOG 1-6
 described, SOG 4-8–SOG 4-9
 high-capacity, SOG 4-7
 feeder trays, clearing faults, TRB 3-2–TRB 3-3
 feeder trays, current configuration, CMS 1-14
 feeder/stacker
 configurations, IPG 3-4–IPG 3-5
 number, IPG 3-8
 options, IPG 3-6–IPG 3-9
 space requirements, IPG 6-7–IPG 6-11
 specifications, IPG 6-29–IPG 6-31
 feeder/stacker module, SOG 4-7
 file pull-down menus, CMS 1-3
 finishing attributes, CMS 4-55
 Finishing field, CMS 1-17
 Finishing Function field, CMS 4-60
 Finishing Function Option field, CMS 4-18
 finishing options, IPG 3-6–IPG 3-9
 floor leveling, IPG 6-24
 fonts
 converting, IPG 1-5
 MICR
 CMC7 series, IPG 1-8
 E13B series, IPG 1-8
 fonts, MICR
 CMC7 fonts, SOG 5-1
 E13B fonts, SOG 5-1
 fonts, resident, CMS 1-11, SOG 1-15
 adding, CMS 3-10
 displaying, CMS 3-9
 friction-type feeders, PRM 1-2
 fuser
 agent, IPG A-12, IPG A-21, SOG A-12, SOG A-22
 shield, IPG A-12, IPG A-21, SOG A-12, SOG A-22
 fuser agent
 adding, PRM 3-1–PRM 3-4
 fuser power saver, SOG 4-15

G

glazing, TRB 3-4

GOCA (Graphics Object Content Architecture), SOG 1-5
 graphical user interface, *see* GUI
 Guarded Tools icon, SOG 4-5
 GUI, CMS 1-1–CMS 1-9, SOG 3-2–SOG 3-3
 guidelines, loading paper, PRM 1-2

H

hard disk, SOG 2-3
 hardware
 configuration, IPG 3-4–IPG 3-5
 controller components, IPG 2-1, IPG 5-9
 printer components, IPG 6-29–IPG 6-31
 specifications, IPG 5-9–IPG 5-10, IPG 6-29–IPG 6-31
 supported, IPG 6-12
 hardware features, SOG 1-6
 HCF feeder trays
 capacities, SOG 4-9
 control panel, SOG 4-9
 HCU, IPG 2-1, IPG 2-10, IPG 5-8, IPG 5-9, SOG 2-1, SOG 2-5
 HCU errors, TRB 3-8
 HCU, powering on, CMS 2-2
 HFSI (high frequency service indicator), CMS 1-1, SOG 3-2
 high-capacity feeder, SOG 4-7
 high-capacity stacker, SOG 4-7, SOG 4-10–SOG 4-11
 high-capacity stacker (HCS) bins, PRM 2-2
 high-speed transfer mode, CMS 3-4
 Hint icon, SOG 4-5, TRB 2-1
 Host Channel Unit, *see* HCU
 Host Channel Unit, *see* HCU
 host computer, communicating, CMS 2-5–CMS 2-6
 Host Job Control section, CMS 1-20
 HPPCL5e, IPG 1-6
 Human Readable Interpretation (HRI), SOG 1-15

I

IBM AFP architecture, IPG 1-1
 IBM AFP Group 3 page printer, SOG 1-1
 IBM IPDS Group 3 page printer, IPG 1-1
 IBM, outline fonts, SOG 1-15
 icons, moving, CMS 1-6
 IEEE
 802.3, IPG 4-7
 images, full-page 600 dpi, SOG 1-14
 In Use indicator, SOG 4-11
 incremental spin buttons, CMS 1-5
 ink, dry, IPG A-21, SOG A-22

CMS = Guide to Configuring and Managing the System
IPG = Installation Planning Guide
PRM = Guide to Performing Routine Maintenance
SOG = System Overview Guide
TRB = Troubleshooting Guide

input configuration
 changing, CMS 4-46
 creating, CMS 4-40–CMS 4-45
 deleting, CMS 4-47
 example, CMS 4-29

Input Configuration section, CMS 1-14–CMS 1-15,
 CMS 4-28

input enablement
 kit, SOG 4-14
 paper path, SOG 4-17

input enablement devices, IPG 6-20

input tray, capabilities, SOG 1-11

input trays, IPG 1-4, SOG 1-6

input trays, configuring, CMS 1-14

input trays, loading, PRM 1-1–PRM 1-9

installation
 planning checklist, IPG 4-4–IPG 4-6
 preparation, IPG 4-1–IPG 4-7
 process, IPG 8-1
 Xerox responsibilities, IPG 4-1

instruction labels, SOG 4-15

interface, CMS 1-11

inverter feeder/stacker, IPG 3-1, IPG 3-4, IPG 3-7,
 IPG 3-9

inverter feeder/stacker module, SOG 4-7

IOCA (Image Object Content Architecture), SOG 1-5

IOCA Replicate and Trim, SOG 1-12

IOT (Image Output Terminal), *see* printer

IPDS bins, CMS 1-16

IPDS data streams, CMS 3-16, IPG 1-6, SOG 1-1,
 SOG 1-5

IPDS Trays field, CMS 1-15, CMS 4-43

IPS Authorization, CMS 1-13

IPS console window, IPG 2-9

IPS Engine Monitor window, CMS 1-1, SOG 3-2

IPS main window, IPG 2-9
 buttons, CMS 1-21–CMS 1-22
 components, CMS 1-9–CMS 1-22, SOG 3-4–
 SOG 3-5
 described, CMS 1-1, SOG 3-2
 description, SOG 1-2, SOG 1-10
 Host Job Control section, CMS 1-20
 menus, CMS 1-10–CMS 1-14
 setup and status information, CMS 1-18–CMS
 1-19
 using, CMS 1-9

IPS mode, switching, CMS 3-16

IPS Output Configuration window, CMS 4-51

IPS Print Engine Monitor window, CMS 2-6

IPS print engine monitor window, IPG 2-9

IPS Print Service Console window, CMS 1-1, SOG
 3-2

IPS screen, IPG 2-9

IPS software license text string, loading, CMS 3-12–
 CMS 3-13

ISO specifications, IPG 1-7

J

jam clearance assistance, SOG 4-15

JCL keyword, SOG 1-11

JES2
 FSS statement parameters, IPG E-3–IPG E-4
 Initialization Dataset commands example, IPG
 E-4
 printer definitions, IPG D-1

JES3
 configuring, IPG E-4
 FSS statement parameters, IPG E-5–IPG E-6
 initialization dataset commands example, IPG
 E-6

job integrity, checking after paper jam, TRB 3-8

K

keyboard, IPG 2-4, IPG 2-7, IPG 5-10, SOG 2-4

keyboard, cleaning, PRM 6-1

L

labels
 selecting, IPG A-2, SOG A-2

language, CMS 1-11

Language icon, SOG 4-4

language, messages, SOG 1-15

length guide, PRM 1-5

leveling, floor, IPG 6-24

License Status, CMS 1-13

license, software, SOG 1-17

licensing, software, IPG 8-3

lights, feeder trays, PRM 1-1

loading
 paper, PRM 1-2
 trays 1 and 2, PRM 1-3–PRM 1-6
 trays 3,4,5, and 6, PRM 1-7–PRM 1-9

loading, feeder trays, PRM 1-1–PRM 1-9

logging, service call, CMS 1-12

M

magnetic ink character recognition *see* MICR

maintenance
 ongoing, IPG 8-4
 routine, IPG 8-4

maintenance services, PRM 7-1–PRM 7-4

mapping IPDS bins, CMS 1-16

CMS = Guide to Configuring and Managing the System

IPG = Installation Planning Guide

PRM = Guide to Performing Routine Maintenance

SOG = System Overview Guide

TRB = Troubleshooting Guide

mapping IPDS input trays, CMS 4-43
 margin values, CMS 4-31
 masking faults, TRB 2-1–TRB 2-2
 maximum simplex, CMS 1-11
 Maximum Simplex window, CMS 4-8
 media defaults, editing, CMS 4-38
 media icon
 changing, CMS 4-38
 creating, CMS 4-33–CMS 4-37
 deleting, CMS 4-38
 Media Library window, CMS 4-33
 Media Library, setting up, CMS 4-32–CMS 4-38
 Media Type window, CMS 4-34
 Media Units
 specifying size units, CMS 4-12
 specifying weight units, CMS 4-12
 media units
 specifying, CMS 1-11
 menus
 Administration, CMS 1-13
 Bin Selection Mode, CMS 4-52
 Channel Mode, CMS 3-4
 Configuration, CMS 1-11, CMS 4-6–CMS 4-14
 DFA Profile, CMS 4-53
 Diagnostics, CMS 1-12, CMS 4-15
 System Options, CMS 1-14, CMS 4-27
 Trace Mode Options, CMS 4-21
 messages
 area, SOG 4-6
 HFSI, CMS 1-1, SOG 3-2
 translation, SOG 1-15
 meter readings, displaying, CMS 1-13
 meter, billing
 reading, IPG 8-4
 reporting, IPG 8-4
 MICR
 comparator with MICR grid, IPG A-14, SOG 5-4,
 SOG A-14
 dry ink, IPG A-12, IPG A-21, SOG A-12, SOG
 A-22
 fonts, IPG 1-8, SOG 5-1
 line, IPG 1-7
 output, readability, SOG 5-3
 Positioning and Dimension Gauge, IPG A-14,
 SOG A-14
 printing features, SOG 5-1–SOG 5-2
 MICR Clear Band, SOG 5-3
 MICR Grid, SOG 5-4
 MICR line, SOG 5-3
 MICR mode, CMS 1-11, CMS 1-18
 MICR Mode screen, SOG 5-2
 MICR Mode Selection window, CMS 4-11
 MICR mode, selecting, CMS 4-11

MICR Position and Dimension Gauge, SOG 5-4
 Minimum Set Time field, CMS 4-59
 misfeeds, frequent, TRB 3-4–TRB 3-5
 mixed paper sizes, printing on, SOG 1-11
 mixed plex, SOG 1-12
 mixed plex feature, IPG 1-5
 MO:DCA-P (Mixed Object Document Content
 Architecture for Presentation, SOG 1-5
 Mode field, CMS 4-18
 modem
 enable and disable, TRB 1-2
 modem, enable or disable, CMS 1-11, CMS 3-6, SOG
 1-17
 modes, switching, CMS 3-16
 monitor, IPG 2-3, IPG 5-9, SOG 2-4
 monitor, blank display, TRB 6-1
 monitor, cleaning, PRM 6-1
 monthly print volume, IPG 1-3, SOG 1-3
 mouse, IPG 2-4, IPG 2-8, IPG 5-10, SOG 2-4
 MVS
 channel attachment, IPG D-1–IPG D-3
 TCP/IP connection, IPG E-1–IPG E-17

N

network configurations
 AIX, IPG E-26
 AS/400, IPG E-18
 MVS, IPG E-2
 OS/2, IPG E-28
 network interface requirements, IPG 4-7
 NPS mode, switching, CMS 3-16
 null modem connection, CMS 1-12
 Number of Sets field, CMS 4-18
 Number of Sheets field, CMS 4-18
 N-Up, enhanced, SOG 1-13

O

OCA colors, SOG 1-13
 Offline field, CMS 4-21
 offline, taking, CMS 1-14, CMS 2-5, CMS 4-27
 Online field, CMS 4-21
 online, placing, CMS 1-14, CMS 2-5
 On-Ups symbol, SOG 5-3
 operating systems supported, IPG 1-1
 Operator Mode, CMS 4-2
 operator training, PRM 7-2
 optical mouse, SOG 2-4
 optional processing parameters
 setting, CMS 1-11
 Optional Processing Parameters window, CMS 4-14
 options, IPG 3-6–IPG 3-8

CMS = Guide to Configuring and Managing the System

IPG = Installation Planning Guide

PRM = Guide to Performing Routine Maintenance

SOG = System Overview Guide

TRB = Troubleshooting Guide

- ordering supplies, IPG A-22, SOG A-23
 - OS/2
 - examples, IPG D-4–IPG D-5
 - parameters, IPG E-28–IPG E-35
 - OS/390, *see* MVS
 - outlets, power configurations, IPG 5-2, IPG 6-2
 - outline fonts, SOG 1-15
 - output bins, IPG 1-6, SOG 1-11
 - output configuration
 - changing, CMS 4-57
 - creating, CMS 4-51–CMS 4-54
 - deleting, CMS 4-57
 - DFA profile
 - adding, CMS 4-58–CMS 4-61
 - changing, CMS 4-62
 - deleting, CMS 4-62
 - example, CMS 4-53
 - specifying, CMS 4-49–CMS 4-62
 - Output Configuration section, CMS 1-16–CMS 1-17
 - Output Configuration window, SOG 1-11
 - Output DFA Profile window, CMS 4-58
 - output trays, PRM 2-1–PRM 2-3
 - overstrike support, SOG 1-13
- P**
-
- pad, IPG 2-8
 - Page Order Within Set field, CMS 1-17
 - page rotation, SOG 1-14
 - Pages Outstanding display, CMS 1-19
 - paper
 - characteristics, IPG A-2, SOG A-2
 - conditioning, IPG A-10–IPG A-11, SOG A-10–SOG A-11
 - curl, TRB 3-23
 - adjusting, TRB 3-24
 - measuring, TRB 3-23
 - feed direction, IPG A-6–IPG A-8, SOG A-6–SOG A-8
 - handling, advanced, IPG 1-4
 - jams, TRB 3-23
 - jams, clearing
 - bypass transport, TRB 3-21–TRB 3-22
 - checking job integrity, TRB 3-8
 - steps, TRB 3-7
 - loading, PRM 1-2
 - ordering, IPG A-15–IPG A-21, IPG A-22–IPG A-23, SOG A-15–SOG A-22, SOG A-23–SOG A-25
 - path
 - bypass transport, SOG 4-18
 - input enablement, SOG 4-17
 - printer, SOG 4-16
 - path, bypass transport, IPG 6-15
 - performance guides, SOG B-1
 - predrilled, PRM 1-2
 - preprinted, PRM 1-2
 - recommended weight, grade, IPG A-1, SOG A-1
 - selecting, IPG A-1–IPG A-3, SOG A-1–SOG A-3
 - size, IPG 6-12, IPG A-1, SOG A-1
 - sizes, IPG A-3–IPG A-8, SOG A-3–SOG A-8
 - storing, IPG A-9, SOG A-9
 - supplies, IPG A-15–IPG A-20, SOG A-15–SOG A-21
 - trays, *see* trays
 - types, TRB 3-1
 - paper feeder assembly, PRM 1-6
 - Paper Level indicators, SOG 4-9
 - parallel channel interface, CMS 3-4
 - parameters, processing, CMS 4-13
 - PCI Bus support, SOG 1-16
 - PCIM2 card, SOG 2-3
 - PCL data streams, CMS 3-16, SOG 1-1
 - perforated paper, IPG A-3, SOG A-3
 - performance guides, paper, SOG B-1
 - personality profiles, CMS 1-21, CMS 4-58–CMS 4-61
 - personnel, training, IPG 4-3
 - pin buttons, CMS 1-8
 - planning checklist, IPG 4-4–IPG 4-6
 - Please Wait indicator, SOG 4-9, SOG 4-11
 - plex, mixed, SOG 1-12
 - PostScript data streams, CMS 3-16, SOG 1-1
 - PostScript level 2, IPG 1-6
 - power
 - cord configurations, IPG 6-3
 - requirements, IPG 5-1–IPG 5-2, IPG 5-9, IPG 6-1–IPG 6-5, IPG 6-29–IPG 6-31
 - savers, SOG 4-15
 - supply, SOG 2-5
 - power outage, CMS 2-5
 - power saver mode, exiting, CMS 2-7
 - powering off, CMS 2-3–CMS 2-5
 - powering on, CMS 2-1–CMS 2-2
 - power-saver timeout mode, CMS 3-7
 - PQA button, CMS 4-19
 - PQA status window, CMS 4-19
 - precut paper, IPG A-3, SOG A-3
 - predrilled paper, IPG A-2, PRM 1-2, SOG A-2
 - preprinted paper, IPG A-2, PRM 1-2, SOG A-2
 - print job
 - automatic recovery, CMS 2-7
 - starting, CMS 2-6
 - print jobs, automatic recovery, TRB 3-8
 - print volume, monthly, IPG 1-3, SOG 1-3
 - printer
 - activity, displaying, CMS 1-19

CMS = Guide to Configuring and Managing the System

IPG = Installation Planning Guide

PRM = Guide to Performing Routine Maintenance

SOG = System Overview Guide

TRB = Troubleshooting Guide

- attention
 - alarm, IPG 3-1
 - light, IPG 3-1
- components, IPG 3-1–IPG 3-3
- configuration options, IPG 3-6–IPG 3-9
- configurations, IPG 3-4–IPG 3-5
- control console, IPG 3-2–IPG 3-3
- defining, IPG 8-3
- dimensions, IPG 6-7–IPG 6-11
- installation, IPG 8-1
- IPDS bins, mapping, CMS 1-16
- maintenance, IPG 8-4
- performance
 - AS/400, IPG E-24
 - MVS, IPG E-16
 - OS/2, IPG E-34–IPG E-35
- pinging
 - AS/400, IPG E-22–IPG E-24
 - MVS, IPG E-14–IPG E-15
 - OS/2, IPG E-32–IPG E-33
- placement, IPG 6-7
- power requirements, IPG 6-29–IPG 6-31
- purge tray, IPG 3-1
- queues
 - PSF/2, defining, IPG E-31–IPG E-32
- resuming, CMS 2-7
- sample definitions
 - MVS with channel attachment, IPG D-1–IPG D-3
 - MVS with TCP/IP connection, IPG E-1–IPG E-17
 - OS/2 with channel attachment, IPG D-4–IPG D-5
 - VM with channel attachment, IPG D-6
 - VSE with channel attachment, IPG D-6
- sample tray, IPG 3-1
- stacker trays, configuring, CMS 1-16
- status, CMS 2-6
- stopping, CMS 2-6
- throughput speed, IPG 6-12, IPG A-3–IPG A-4, SOG A-3–SOG A-4
- Printer Bins display field, CMS 1-16
- printer control console
 - components, SOG 4-3–SOG 4-6
 - described, SOG 4-3
- Printer Controller
 - components, SOG 2-1–SOG 2-5
 - HCU, SOG 2-1
 - Sun UltraSPARC workstation, SOG 2-1
- description, SOG 1-2
- keyboard, SOG 2-4
- monitor, SOG 2-4
- mouse, SOG 2-4
- processor
 - CD-ROM drive, SOG 2-4
 - described, SOG 2-3–SOG 2-4
 - hard disk, SOG 2-3
 - rebooting, CMS 2-7
 - setting up, CMS 3-1–CMS 3-16
- printer controller
 - components, IPG 2-1–IPG 2-10
 - placement, IPG 5-3–IPG 5-8
 - power requirements, IPG 5-9–IPG 5-10
 - space requirements, IPG 5-3–IPG 5-8
- Printer Controller exterior, cleaning, PRM 6-1
- Printer icon, SOG 4-4
- printer tray cells, CMS 4-42
- Printer Tray field, CMS 4-18
- Printer Trays field, CMS 1-15, CMS 4-41
- printers
 - capabilities, SOG 1-1
 - components, SOG 4-2–SOG 4-6
 - attention light, SOG 4-6
 - feeder/stacker module, SOG 4-7
 - high-capacity feeder trays, SOG 4-7
 - high-capacity stacker, SOG 4-7, SOG 4-10–SOG 4-11
 - inverter feeder/stacker module, SOG 4-7
 - printer control console, SOG 4-3, SOG 4-3–SOG 4-6
 - processor feeder trays, SOG 4-2, SOG 4-7
 - purge tray, SOG 4-6
 - sample tray, SOG 4-6
 - configurations, SOG 4-12–SOG 4-13
 - description, SOG 1-2
 - paper jam areas, TRB 3-9–TRB 3-20
 - paper path, SOG 4-16
 - restarting, TRB 6-3
- printing
 - pages remaining display, CMS 1-19
 - samples, CMS 4-15–CMS 4-19
 - test patterns, CMS 4-15
- printing test jobs
 - OS/2, IPG E-33
- privilege mode, CMS 4-2
 - Administrator Mode, CMS 4-2
 - changing, CMS 1-13, CMS 4-3, CMS 4-4
 - display on main window, CMS 1-18
 - Operator Mode, CMS 4-2
 - Service Mode, CMS 4-2
 - User Mode, CMS 4-2
- privilege modes, SOG 1-16
- procedures
 - 4mm cartridge tape drive, cleaning, PRM 6-1
 - channel connection, switching, CMS 3-3–CMS 3-5

CMS = Guide to Configuring and Managing the System

IPG = Installation Planning Guide

PRM = Guide to Performing Routine Maintenance

SOG = System Overview Guide

TRB = Troubleshooting Guide

- channel interface, selecting, CMS 3-4
 - debug level, setting, CMS 4-24
 - DFA profiles
 - changing, CMS 4-62
 - creating, CMS 4-58–CMS 4-61
 - deleting, CMS 4-62
 - dry ink
 - waste container, replacing, PRM 5-1–PRM 5-3
 - dry ink, adding, PRM 4-1–PRM 4-3
 - duplex mode
 - specifying simplex value, CMS 4-8, CMS 4-12
 - feed belt, cleaning, TRB 3-4–TRB 3-5
 - fuser agent, adding, PRM 3-1–PRM 3-4
 - host jobs, printing, CMS 2-6
 - input configuration
 - changing, CMS 4-46
 - creating, CMS 4-40–CMS 4-45
 - deleting, CMS 4-47
 - IPS mode, switching, CMS 3-16
 - media icon
 - changing, CMS 4-38
 - creating, CMS 4-33–CMS 4-37
 - deleting, CMS 4-38
 - memory allocation, changing, CMS 3-8
 - MICR mode, selecting, CMS 4-11
 - NPS mode, switching, CMS 3-16
 - output configuration
 - changing, CMS 4-57
 - creating, CMS 4-51–CMS 4-54
 - deleting, CMS 4-57
 - paper trays, clearing misfeeds, TRB 3-2–TRB 3-3
 - personality profiles
 - deleting, CMS 4-62
 - powering off, CMS 2-4
 - powering on, CMS 2-2
 - Printer Controller, rebooting, CMS 2-7
 - printers, restarting, TRB 6-3
 - resolution, specifying input, CMS 4-7
 - sample files, printing, CMS 4-15–CMS 4-18
 - sensors, cleaning
 - Q1011, PRM 6-3
 - Q850, PRM 6-2
 - stacker bins, unloading, PRM 2-2–PRM 2-3
 - TCP/IP
 - selecting, CMS 3-5
 - switching, CMS 3-3–CMS 3-5
 - trace
 - capturing, CMS 4-20–CMS 4-22
 - executing captured, CMS 4-22
 - printing, CMS 4-23
 - trays 1 and 2, loading, PRM 1-3–PRM 1-6
 - trays 3, 4, 5, and 6, loading, PRM 1-7–PRM 1-9
 - updating software
 - from CD, CMS 4-25
 - from diskette, CMS 4-25
 - remotely, CMS 4-26
 - processing parameters, setting, CMS 4-13
 - processor, IPG 2-2, IPG 2-5, IPG 5-9
 - processor feeder trays, SOG 4-2, SOG 4-7
 - program temporary fixes, see PTFs
 - programmable bypass transport, see bypass transport
 - PSF
 - handshaking, IPG 2-10
 - printer definitions, IPG D-1
 - PSF compatibility, SOG 1-1
 - PSF/2, defining printer, IPG E-30–IPG E-31
 - PSF/MVS
 - configuring, IPG E-7
 - PRINTDEV statement example, IPG E-11
 - PRINTDEV statement parameters, IPG E-7–IPG E-10
 - PT2 Subset, SOG 1-13
 - PTFs, IPG E-25
 - PTOCA (Presentation Text Object Content Architecture), SOG 1-5, SOG 1-13
 - publications, related, see documentation
 - pull-down menus
 - selecting
 - click method, CMS 1-4
 - drag method, CMS 1-4
 - types, CMS 1-3
 - purge tray, SOG 4-6
 - purge trays, PRM 2-1
- Q**
-
- Q1011 sensor and mirror, cleaning, PRM 6-3
 - Q1106 sensor, cleaning, PRM 6-5
 - Q1107 sensor, cleaning, PRM 6-4
 - Q1107A sensor, TRB 3-20
 - Q1164 sensor, cleaning, PRM 6-6
 - Q1166 sensor, cleaning, PRM 6-5
 - Q850 sensor, cleaning, PRM 6-2
 - Quit buttons, CMS 1-21
- R**
-
- raster output scanner (ROS) power saver, SOG 4-15
 - Ready To Open indicator, TRB 3-2
 - Ready to Open indicator, PRM 1-3, SOG 4-9
 - Ready to Unload indicator, PRM 2-2, SOG 4-11
 - Recovery Control field, CMS 4-60
 - reflected light, MICR comparator, SOG 5-4

CMS = Guide to Configuring and Managing the System

IPG = Installation Planning Guide

PRM = Guide to Performing Routine Maintenance

SOG = System Overview Guide

TRB = Troubleshooting Guide

reflective surfaces, cleaning, PRM 6-1
 registration transport roll levers, adjusting, TRB 4-1
 remote service, SOG 1-17, TRB 1-2
 Reporting billing meters, PRM 7-3
 requirements
 see also specifications
 clearance space, IPG 6-20–IPG 6-23
 delivery access, IPG 6-24–IPG 6-28
 environmental, IPG 6-6
 Ethernet, IPG 4-7
 network interface, IPG 4-7
 power, IPG 5-1–IPG 5-2, IPG 5-9, IPG 6-1–IPG
 6-5, IPG 6-29–IPG 6-31
 printer controller space, IPG 5-3–IPG 5-8
 space, IPG 5-3, IPG 6-7, IPG 6-20–IPG 6-28
 Token Ring, IPG 4-7
 Reset button, CMS 1-22
 Reset Now button, CMS 1-22
 resident fonts, CMS 1-11, SOG 1-15
 adding, CMS 3-10
 displaying, CMS 3-9
 resolution, CMS 1-11, CMS 4-6, IPG 1-5
 MICR, 300/600 dpi, SOG 5-2
 Resolution display, CMS 1-18
 Resolution window, CMS 4-6
 Resource Limits, CMS 1-11
 responsibilities
 customer, IPG 4-2–IPG 4-3
 installation
 customer, IPG 8-2
 Xerox, IPG 8-2
 Xerox, IPG 4-1–IPG 4-2
 restoring configuration files, CMS 1-13, CMS 4-63
 RISC processor chipset, SOG 2-1
 RISC-based controller, IPG 1-1
 roll feeder, IPG 1-4
 Rotation display, CMS 1-18

S

S/370 bus, IPG 2-10
 saddle-stitching, IPG 1-6
 Sample button, SOG 4-5
 Sample File field, CMS 4-16
 sample printer definitions
 MVS with channel attachment, IPG D-1–IPG D-3
 MVS with TCP/IP connection, IPG E-1–IPG E-17
 OS/2 with channel attachment, IPG D-4–IPG D-5
 VM with channel attachment, IPG D-6
 VSE with channel attachment, IPG D-6
 Sample printing window, CMS 4-15
 sample tray, SOG 4-6
 sample trays, PRM 2-1

samples, printing, CMS 1-12, CMS 4-15–CMS 4-19
 Save button, CMS 1-22
 SCSI cartridge tape drive, IPG 2-3, IPG 2-6
 selecting
 labels, IPG A-2, SOG A-2
 paper
 characteristics, IPG A-2, SOG A-2
 size, IPG A-1–IPG A-3, SOG A-1–SOG A-3
 transparencies, IPG A-2, SOG A-2
 selecting MICR mode, CMS 4-11
 sensors, cleaning
 methods, PRM 6-1
 Q1011, PRM 6-3
 Q1106, PRM 6-5
 Q1107, PRM 6-4
 Q1166, PRM 6-5
 Q850, PRM 6-2
 service
 telephone number, IPG B-1
 Xerox responsibilities, IPG 4-2
 service call, logging, CMS 1-12
 service call, required information, TRB 1-1
 Service Mode, CMS 4-2
 service mode, CMS 1-12
 service telephone number, PRM 7-1
 Set Jam Time field, CMS 4-60
 setup information, CMS 1-18–CMS 1-19
 shared space, IPG 6-20, IPG 6-20–IPG 6-23
 Sheet Exit to EndofSet Time field, CMS 4-61
 Sheet Jam Time field, CMS 4-60
 shutdown system, CMS 1-14
 silicone, PRM 3-2
 simplex
 maximum duplex, CMS 1-11
 mode, specifying value maximum, CMS 4-8
 printing, selecting, CMS 4-30
 simplex, duplex flexibility, SOG 1-12
 single-tag interlock mode, CMS 3-4
 site
 personnel, customer responsibility, IPG 4-2
 preparation, customer responsibility, IPG 4-2
 selection, Xerox responsibilities, IPG 4-1
 Sixth Sense feature, IPG B-2
 Sixth Sense Technology, SOG 1-17, TRB 1-2
 disabling a modem, TRB 1-3
 enabling a modem, TRB 1-3
 remote service, TRB 1-2
 size units, specifying, CMS 4-12
 skewed printing, correcting, TRB 4-1
 slumber mode timer, CMS 1-11, CMS 3-7
 SMM Value for Finishing Function field, CMS 4-60
 software
 features, IPS, SOG 1-11

CMS = Guide to Configuring and Managing the System

IPG = Installation Planning Guide

PRM = Guide to Performing Routine Maintenance

SOG = System Overview Guide

TRB = Troubleshooting Guide

- licensing, IPG 8-3
 - supported products, SOG 1-5
- Software license, SOG 1-17
- software license text string, loading, CMS 3-12–CMS 3-13
- software prerequisites
 - AIX, IPG E-25
 - AS/400, IPG E-18
 - MVS, IPG E-1
 - OS/2, IPG E-28
- software updates
 - from CD, CMS 1-12, CMS 4-25
 - from diskette, CMS 1-12, CMS 4-25
 - remotely, CMS 1-12, CMS 4-26
- space
 - bypass transport, IPG 6-14
 - planning guidelines, IPG 6-20
 - requirements, IPG 5-3, IPG 6-7, IPG 6-20–IPG 6-28
- specifications
 - see also* requirements
 - bypass transport, IPG 6-12–IPG 6-16
 - controller, IPG 5-1–IPG 5-10
 - electrical, IPG 5-9, IPG 6-1–IPG 6-5, IPG 6-29–IPG 6-31
 - printer, IPG 6-1–IPG 6-31
- stacker
 - high-capacity, SOG 4-7, SOG 4-10–SOG 4-11
- stacker problems, TRB 5-1
- stacker trays, configuring, CMS 1-16
- stacker, unloading bins, PRM 2-2–PRM 2-3
- status information, CMS 1-18–CMS 1-19
- Status section, CMS 1-19
- Statuses Supported field, CMS 4-60
- Stop button, CMS 1-20, SOG 4-5
- subscriber support, SOG 1-13
- Sun workstation, SOG 2-2
- Sun workstations, IPG 1-1, IPG 2-1–IPG 2-4, IPG 2-4–IPG 2-8, IPG 5-4, IPG 5-6
- superscript support, SOG 1-13
- supplies
 - cartridge tapes, IPG A-13, SOG A-13
 - checklist, IPG A-25–IPG A-26, SOG A-25–SOG A-26
 - cleaning, IPG A-21, SOG A-22
 - consumable tables, IPG A-15–IPG A-21, SOG A-15–SOG A-22
 - developer, IPG A-12, IPG A-21, SOG A-12, SOG A-22
 - diskettes, IPG A-13, IPG A-21, SOG A-13, SOG A-22
 - dry ink
 - toner, IPG A-12, IPG A-21, SOG A-12, SOG A-22
 - waste bottle, IPG A-21, SOG A-22
 - fuser
 - agent, IPG A-12, IPG A-21, SOG A-12, SOG A-22
 - shield, IPG A-12, SOG A-12
 - MICR tools, IPG A-14, SOG A-14
 - paper, IPG A-1–IPG A-11, IPG A-15–IPG A-20, SOG A-1–SOG A-11, SOG A-15–SOG A-21
- supplies table, IPG A-15–IPG A-21, SOG A-15–SOG A-22
- support services, IPG B-1–IPG B-4, PRM 7-1–PRM 7-4
- system
 - changing settings, CMS 1-21
 - current configuration, displaying, CMS 1-18
 - interface, specifying, CMS 3-3–CMS 3-5
 - powering off, CMS 2-3–CMS 2-5
 - powering on, CMS 2-1–CMS 2-2
 - setting configuration, CMS 4-1–CMS 4-65
 - shutting down, CMS 1-14
 - starting and stopping, CMS 2-1–CMS 2-7
 - system controller, *see* Printer Controller
 - System Options pull-down menu, CMS 1-14, CMS 4-27
 - System Resource Limits window, CMS 3-8
 - System Shutdown Confirmation window, CMS 2-4
 - system unresponsive, TRB 6-1

T

- tab stock, PRM 1-2
- tape drive, IPG 2-3, IPG 2-6, IPG 5-9, SOG 2-4
- TCP/IP, SOG 1-4
 - configuration, IPG 1-3
 - defining, IPG E-1–IPG E-35
 - Ethernet interface, IPG 1-2
- MVS
 - configuring, IPG E-11
 - Profile dataset
 - parameters, IPG E-12
 - statements example, IPG E-13
 - option, CMS 3-3
 - receiving data, CMS 2-5, CMS 3-5
- TCP/IP Interface window, CMS 3-5
- telephone numbers
 - service, IPG B-1
 - Xerox Parts and Product Support Center, IPG A-22, SOG A-23
- test patterns, printing, CMS 4-15
- Testdocs menu, CMS 4-16–CMS 4-19

CMS = Guide to Configuring and Managing the System

IPG = Installation Planning Guide

PRM = Guide to Performing Routine Maintenance

SOG = System Overview Guide

TRB = Troubleshooting Guide

third party finisher, IPG 3-6
 throughput speed, SOG 1-3
 Time Between Sets field, CMS 4-59
 Time Between Sheets field, CMS 4-59
 Time to Cycle Up field, CMS 4-59
 tinted paper, IPG A-2, SOG A-2
 Token Ring, CMS 2-5, CMS 3-5, IPG 1-2, IPG 2-1,
 IPG 2-4, IPG 4-7, SOG 2-3
 toner, see dry ink
 trace
 capturing, CMS 4-20
 executing, CMS 4-22
 initiating, CMS 4-20–CMS 4-22
 options, CMS 1-12
 printing, CMS 4-23
 Trace display, CMS 1-19
 trace facility, SOG 1-13
 Trace Mode Options pull-down menu, CMS 4-21
 Trace Mode Options window, CMS 4-21
 Trace window, CMS 4-21
 training, IPG 4-2, IPG 4-3, IPG 8-1, IPG B-3
 training, operators, PRM 7-2
 Transfer Assist Blade, SOG 5-2
 transit symbols, SOG 5-3
 transmission rate, IPG 1-2
 transmitted light, MICR comparator, SOG 5-4
 transparencies
 selecting, IPG A-2, SOG A-2
 transparencies, loading, PRM 1-2
 Tray Unlock button, PRM 1-3, TRB 3-2
 trays
 capacities
 feeder, IPG 1-4, SOG 1-6
 HCF, SOG 4-8
 feeder, SOG 4-8–SOG 4-9
 input capabilities, SOG 1-11
 loading
 1 and 2, PRM 1-3–PRM 1-6
 3,4,5, and 6, PRM 1-7–PRM 1-9
 loading feeder, PRM 1-1–PRM 1-9
 output, PRM 2-1–PRM 2-3
 output bins, SOG 1-11
 processor feeder, SOG 4-2, SOG 4-7
 purge, PRM 2-1, SOG 4-6
 sample, PRM 2-1, SOG 4-6
 selecting, SOG 1-11
 trays, stacker, CMS 1-16
 trimming, IPG 1-6
 turning radius, IPG 6-25–IPG 6-28

U

UltraSPARC workstation, SOG 2-1

UltraSPARC workstation, see Sun workstations
 underscore support, SOG 1-13
 United States/Canada, IPG 5-2
 units, specifying (weight, size), CMS 4-12
 unloading
 high-capacity stacker (HCS) bins, PRM 2-2
 purge trays, PRM 2-1
 sample trays, PRM 2-1
 stacker bins, PRM 2-2–PRM 2-3
 updates, software
 from CD, CMS 1-12, CMS 4-25
 from diskette, CMS 1-12, CMS 4-25
 remotely, CMS 1-12, CMS 4-26
 updating configuration files, CMS 1-21
 User Mode, CMS 4-2

V

vacuum-type feeders, PRM 1-2
 version identifier, configuration files, SOG 1-15
 vertical clearance, IPG 6-7
 VM, IPG D-6
 voltages, requirements, IPG 5-2
 VSE, IPG D-6

W

waste bottle, dry ink, IPG A-21, SOG A-22
 weight units, specifying, CMS 4-12
 windows
 Add a New Form Type, CMS 4-36
 Ask for File Name, CMS 1-21
 Backup Configuration Files, CMS 4-64
 Channel Options, CMS 3-4
 Default Trace File Name, CMS 4-21
 Edit the Media Defaults, CMS 4-39
 exiting, CMS 1-6
 IPS Engine Monitor, CMS 1-1, SOG 3-2
 IPS main, CMS 1-9, SOG 3-4–SOG 3-5
 IPS main, described, CMS 1-1, SOG 3-2
 IPS Output Configuration, CMS 4-51
 IPS Print Engine Monitor, CMS 2-6
 IPS Print Service Console, CMS 1-1, SOG 3-2
 Maximum Simplex, CMS 4-8
 Media Library, CMS 4-33
 Media Type, CMS 4-34
 MICR Mode Selection, CMS 4-11
 moving, CMS 1-6
 Optional Processing Parameters, CMS 4-14
 Output DFA Profile, CMS 4-58
 PQA status, CMS 4-19
 Resolution, CMS 4-6
 Sample printing, CMS 4-15

CMS = Guide to Configuring and Managing the System

IPG = Installation Planning Guide

PRM = Guide to Performing Routine Maintenance

SOG = System Overview Guide

TRB = Troubleshooting Guide

System Resource Limits, CMS 3-8
System Shutdown Confirmation, CMS 2-4
TCP/IP Interface, CMS 3-5
Trace, CMS 4-21
Trace Mode Options, CMS 4-21
workstations
 processor placement, SOG 2-5
 Sun UltraSPARC, SOG 2-1
workstations see Sun workstations

X

Xerox Customer Documentation Catalog, IPG B-3
Xerox Customer Education, IPG B-4, PRM 7-3
Xerox Customer Parts and Product Support Center,
 IPG A-22, SOG A-23
Xerox Customer Service Support Center, IPG B-1,
 PRM 7-1
Xerox Documentation and Software Services
 (XDSS), IPG B-3, PRM 7-2
Xerox Font Center, IPG B-4, PRM 7-2
Xerox Printing Systems Customer Support Center,
 IPG B-2
Xerox responsibilities, IPG 4-1–IPG 4-2, IPG 8-2
XSIS authorization, CMS 1-13

***CMS** = Guide to Configuring and Managing the System*
***IPG** = Installation Planning Guide*
***PRM** = Guide to Performing Routine Maintenance*
***SOG** = System Overview Guide*
***TRB** = Troubleshooting Guide*

CMS = Guide to Configuring and Managing the System
IPG = Installation Planning Guide
PRM = Guide to Performing Routine Maintenance
SOG = System Overview Guide
TRB = Troubleshooting Guide

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>