



ELECTRONIC CASH REGISTER

PCR-360

OPERATOR'S INSTRUCTION MANUAL



U.S. model



Canada model

CI

CANADA

CASIO®

Welcome to the CASIO PCR-360!

Congratulations upon your selection of a CASIO Personal Cash Register, which is designed to provide years of reliable operation.

Operation of a CASIO cash register is simple enough to be mastered without special training. Everything you need to know is included in this manual, so keep it on hand for reference.

Consult your CASIO dealer if you have any questions about points not specifically covered in this manual.

CASIO AUTHORIZED SERVICE CENTER

If your Casio product needs repair, or you wish to purchase replacement parts, please call 1-800-YO-CASIO for the authorized service center nearest your home.

If for any reason this product is to be returned to the store where purchased, it must be packed in the original carton/package.

If you need programming assistance, please call 1-800-638-9228.

In Canada, Call 1-800-661-2274.

Thank you.

GUIDELINES LAID DOWN BY FCC RULES FOR USE OF THE UNIT IN THE U.S.A. (Not applicable to other areas)

WARNING: This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instruction manual, may cause interference to radio communications. It has been tested and found to comply with the limits for a Class A computing device pursuant to Subpart J of Part 15 of the FCC Rules, which re designed to provide reasonable protection against such interference when operated in a commercial environment.

Operation of this equipment in a residential area is likely to cause interference in which case the user at his/her own expense will be required to take whatever measures may required to correct the interference.


This digital apparatus does not exceed the Class A limits for radio noise emissions from digital apparatus as set out in the Radio Interference Regulations of the Canadian Department of Communications.

The main plug on this equipment must be used to disconnect mains power.
Please ensure that the socket outlet is installed near the equipment and shall be easily accessible.

Introduction	2
Unpacking the register	6
Getting Started	8
Remove the cash register from its box	8
Remove the tape holding parts of the cash register in place	8
Install the three memory backup batteries	8
Plug the cash register into a wall outlet	10
Insert the mode key marked "PGM" into mode switch	10
Turn the mode key to the "REG" position	10
Install receipt/journal paper	10
To load 1-ply paper for printing of receipts	11
To load 1-ply paper for printing of journal	12
To load 2-ply paper for printing of receipts	13
Set the date	14
Set the time	14
Select printouts receipt or journal	14
Programming automatic tax calculation	15
Programming the U.S. Tax Table procedure	15
Programming Canadian Tax table procedure	20
Setting the store telephone number	21
Introducing PCR-360	22
General guide	22
Mode key, Mode switch	23
Drawer	23
Displays	25
Keyboard	26
Basic Operation and Setups	28
How to read the printouts	28
How to Use Your Cash Register	29
Displaying the time and date	30
Preparing coins for change	30
Preparing and using department keys	31
Registering department keys	31
Programming department keys	33
Registering department keys by programming data	35
Preparing and using PLUs	36
Programming PLUs	36
Registering PLUs	38
Preparing and using discounts	40
Programming discounts	40
Registering discounts	41
Preparing and using reductions	42
Programming or reductions	42
Registering reductions	43
Calculating the merchandise subtotal	44

Shifting the taxable status of an item	45
Registering charge and check payments	46
Registering returned goods in the REG mode	47
Registering returned goods in the RF mode	48
Registering money received on account	49
Registering money paid out	49
Making corrections in a registration	50
No sale registration	52
Printing the Daily sales RESET report	53
Convenient Operations and Setups	54
About the clerk control function	54
About post-finalization receipt	55
Programming general printing control	56
Programming compulsory and clerk function	57
Programming READ/RESET report printing control	58
Setting a store/machine number	58
Setting/editing the store telephone number	59
High digit limitation for departments	59
Single-Item-Sales for departments and PLUs	60
Registering Sub-departments	61
Registering discounts and premiums	65
Registering manually entered tax amounts	67
Other programmable options	68
Calculator functions	69
Printing READ/RESET reports	71
Printing the cash register's program	76
Troubleshooting	78
When an error occurs	78
When the register does not operate at all	79
In case of power failure	80
When the L sign appears on the display	80
User Maintenance and Options	81
To replace the ink ribbon	81
To replace journal paper	82
To replace receipt paper	83
Specification	84
Index	85


Unpacking the register




Important!

Before you do anything, be sure to note the following important precautions!


Do not locate the cash register where it will be subjected to direct sunlight, very high humidity, splashing with water or other liquids, or high temperature (such as near a heater).




Be sure to check the sticker on the side of the cash register to make sure that its voltage matches that of the power supply in the area.




Never operate the cash register while your hands are wet.



Use a soft, dry cloth to clean the exterior of the cash register. Never use benzene, thinner, or any other volatile agent.




Never try to open the cash register or attempt your own repairs. Take the cash register to your authorized CASIO dealer for repairs.




Getting Started

This section outlines how to unpack the cash register and get it ready to operate. You should read this part of the manual even if you have used a cash register before. The following is the basic set up procedure, along with page references where you should look for more details.

- 1. Remove the cash register from its box, making sure that all of the parts and accessories are included.**



- 2.**



Remove the tape holding parts of the cash register in place.

Also remove the small plastic bag taped to the printer cover. Inside you will find the mode keys.

- 3.**

Install the three memory backup batteries.





1. Remove the printer cover and inner cover.




2. Remove the battery compartment cover. Pressing down where the cover is marked " " and put it up.


3. Install the three memory backup batteries. (continued...)



3. Note the (+) and (-) markings in the battery compartment. Load a set of three new SUM-3 (UM-3) batteries so that their positive (+) and negative (-) ends are facing as indicated by the marking.



4. Replace the battery compartment cover .



5. Replace the inner cover printer cover .

Important!

These batteries protected information stored in your cash register's memory when there is a power failure or when you unplug the cash register . Be sure to install these batteries.

Precaution!


Incorrectly using batteries can cause them to burst or leak, possibly damaging the interior of the cash register. Note the followings.

- Be sure that the positive (+) and negative (-) ends sides of the batteries are facing as marked in the battery compartment when you load them into the unit.
- Never mix batteries of different types.
- Never mix old batteries with new ones.
- Never leave dead batteries in the battery compartment.
- Remove the batteries if you do not plan to use the cash register for long periods.
- Replace the batteries at least once every two years, no matter how much the cash register is used during the period.

WARNING!

- Never try to recharge the batteries supplied with the unit.
 - Do not expose batteries to direct heat, let them become shorted or try to take them apart.
- Keep batteries out of the reach of small children. If your child should swallow a battery, consult a physician immediately.

4.




Plug the cash register into a wall outlet.

Be sure to check the sticker on the side of the cash register to make sure that its voltage matches that of the power supply in your area. The printer will operate for a few seconds.

5.




Insert the mode key marked "PGM" into the Mode Switch.



6.

Turn the mode key to the "REG" position.

The display should change to the following.





7. Install receipt/journal paper

Important!


**Never operate the cash register without paper.
It can damage the printer.**

7. Install receipt/journal paper (continued...)

To load 1-ply paper for printing of receipts



1 Use a mode key to set the mode switch to REG position



5 Work the paper roll gently between the two spindles so that they slip into the center hubs of the roll.




2 Remove the printer cover




6 Pass paper over silver plate.



3 Cut off the leading end of the paper so it is even.



7 Press the **FEED** key until about 20 cm or 30 cm of paper is fed from the printer.



4 Ensuring the paper is being fed from the bottom of the roll, lower the roll into the space behind the printer.



8 Replace the printer cover, passing the leading end of the paper through the cutter slot. Tear off the excess paper.

7. Install receipt/journal paper (continued...)

To load 1-ply paper for printing of journal

Follow steps ① through ⑦ under "To load 1-ply paper for printing receipts" on the previous page.



⑧

Remove the flat side plate of the take-up reel.



⑫

Press the **FEED** key to take up any slack in the paper.




⑨

Slide the leading end of the paper into the groove on the spindle of the take-up reel and wind it onto the reel two or three turns.



⑬

Replace the printer cover.



⑩

Replace the flat side plate of the take-up reel.



⑪

Place the take-up reel into place behind the printer, above the roll paper.


7. Install receipt/journal paper (continued...)

To load 2-ply paper for printing of receipts

Follow steps ① through ⑤ under "To load 1-ply paper for printing of receipts" above.



⑥ Separate the two sheets of the paper. Pass the outer sheet under the separator.



⑨ Press the **FEED** key until about 20 cm or 30 cm of paper is fed from the printer.



⑦ Pass the inner sheet over the separator.

⑩ Insert the leading end of the inner sheet (which will be your journal) into the take-up reel, as described starting from step ② under "To load 1-ply paper for printing of a journal."




⑧ Join the ends of the paper again and insert them into the paper inlet.

⑪ Replace the printer cover, passing the leading end of the outer sheet through the cutter slot. Tear off the excess paper.



Pass paper over silver plate.



8. Set the date.



Example:

December 6, 1996 ⇨ **9 6 1 2 0 6**

9. Set the time.




Example:

09:05 AM ⇨ **0 9 0 5**

09:20 PM ⇨ **2 1 2 0**

10. Select printouts receipt or journal



Note:

Be sure to select "0" (Receipts) when you use 2-ply paper.

11. Tax table programming

Programming automatic tax calculation

Important!

After you program the tax calculations, you also have to individually specify which departments (page 34) and PLUs (page 36) are to be taxed.

For this cash register to be able to automatically register state sales tax, you must program its tax tables with tax calculation data from the tax table for your state. There are two tax tables (U.S.) and three tax tables (Canada) that you can program for automatic calculation of two separate sales taxes.

Programming for the U.S. Tax Tables Procedure

Find your state in the tables (page 16 ~ 19) and input the data shown in the table.

State sales tax calculation data tables for all of the states that make up the United States are included on the following pages. This data is current as of October 30, 1994. *

*Some data are revised after Oct.30,1994.

Important!


Be sure you use the state sales tax data specifically for your state. Even if your state uses the same tax rate percentage as another state, inputting the wrong data will cause incorrect result.

Programming procedure


Example 1 (Alabama 6% sales tax to Tax Table 1)

Example 2 (Colorado 5.25% sales tax to Tax Table 2)

ALABAMA							
4%	5%	6%	6%	6% (4+1+1)	7%	8%	
0	0	0	0	0	0	0	
1	1	1	1	1	1	1	
1	1	1	1	1	1	1	
10	10	8	9	10	7	6	
30	29	24	20	20	21	18	
54	49	41	40	36	35	31	
73	69	58	55	54	49	43	
110	89	70	70	64	64	56	
				90	85	78	68
				109	110	92	81
						107	93
							106




COLORADO						
4.5%	5%	LOVELAND	5.25%	5.5%		
0	211	0	0	5.25	0	172
1	233	1	1	5002	1	190
5	255	2	1		6	209
17	277	17	18		17	227
33	299	29	18		27	245
55		49	51		45	263
77		68	68		63	281
99		84	84		81	299
122		118			99	
144					118	
166					136	
188					154	



Assign Tax Table 1

- 0
- 1
- 1
- 8
- 24
- 41
- 58


Terminate program



Assign Tax Table 2

- 5.25
- 5002

Terminate program



Getting Started

U.S. TAX TABLES

A

ALABAMA						
4%	5%	6%	6% (4+1+1)	7%	8%	
0	0	0	0	0	0	0
1	1	1	1	1	1	1
1	1	1	1	1	1	1
10	10	8	9	10	7	6
30	29	24	20	20	21	18
54	49	41	40	36	35	31
73	69	58	55	54	49	43
110	89		70	70	64	56
	110		90	85	78	68
			109	110	92	81
					107	93
						106

ALASKA							
KENAI		HOMER/ SELDOVIA		HAINES	JUNEAU	KENAI 5%	KENAISEWARD & SOLDOTNA 5%
2%	3%	3%	4%	4%			
0	0	0	0	0	0	0	177
1	1	1	1	1	1	1	184
1	1	1	1	1	1	1	218
1	4	4	2	1	6	6	
25	34	25	19	12	13	13	09
75	49	34	37	37	25	25	29
	83	75	62		46	46	49
	116	127			75	75	69
	150	155			79	79	89
	183	177			118	118	109
	216	227			127	127	
					151	151	

ALASKA				
HOMER		6%		
5.5%				
0	145	345	6	159
1	163	363	2	179
1	181	381	29	199
8	208	408	29	219
27	227		49	239
45	245		69	259
63	263		89	259
81	281		109	279
99	299		109	300
108	308		129	
127	327		159	

ARIZONA						
4%	5%	6%	6.5%	6.7%	6.8%	7%
0	0	0	175	0	161	0
1	1	1	191	1	176	1
1	5	9		7	192	7
12	10	10		7	207	7
37	27	22		23	223	22
	47	39		38	238	37
	68	56		53	253	52
	89	73		69	269	67
	109	90		84	284	82
				107	299	97
				125	115	111
				141	130	126
				158	146	141
						139
						330

ARKANSAS							
3%	4%	5%	6%	6.8%	7%	7.5%	
0	0	0	0	0	0	0	0
1	1	1	1	1	1	1	1
1	1	1	1	2	1	2	2
14	12	10	8	6	7	6	6
44	37	20	24	19	21	19	19
74		40	41	33	35	33	33
114		60	58	46	49	46	46
		80			64	64	64
		110			78	78	78
					92	92	92
					107	107	107

C

CALIFORNIA													LOS ANGELES 10% Parking				
6%	6.25%	6.5%	6.75%	7%	7.25%	7.25%	7.5%	7.75%	8.25%	8.5%							
0	141	0	0	130	299	6.75	0	121	278	7.25	117	7.25	0	7.75	8.25	0	99
1	158	1	1	146		5002	1	135	292	5002	131	5002	1	5002	5002	1	99
7		7	7	161			0	8	149				0			1	104
10		10	10	176			10	10	164		10		6			5	114
22		21	20	192			20	20	178		20		19			17	124
39		37	35	207			34	33	192		32		33			29	134
56		54	51	223			48	47	207		46		46			41	144
73		70	67	238			64	62	221		60		59			52	154
90		86	83	253			80	76	235		74		73			64	
108		103	99	269			96	91	249		88					76	
124		119	115	284			111	107	264		103					88	

COLORADO																			
LOVELAND																			
1.5%	2%	2.5%	3%	3.5%	3.6%	3.85%	4%	4.5%	5%	5%	5.25%	5.5%	5.6%	5.75%	6%	6.1%	6.35%	6.4%	
0	0	0	0	0	0	264	0	0	0	211	0	0	5.25	0	172	0	168	0	165
1	1	1	1	1	1	291	1	1	1	233	1	1	5002	1	190	1	186	1	182
1	1	1	3	2	5	319	2	2	5	255	2	1		6	209	7	204	8	199
33	24	19	17	17	17	347	16	17	17	277	17	18		17	227	16	222	17	217
99	74	59	49	42	41	375	37	37	33	299	29	18		27	245	25	240	26	24
166			83	71	69		63	62		55		51		45	263	43		43	41
233			116	99	97					77		68		63	281	61	60	60	58
			149	128	124					99		84		81	299	79	78	74	74
			183	157	152					122		118		99		97	95		
				185	180					144				118		115	113		
				214	208					166				136		132	130		
				242	236					188				154		150	147		

COLORADO												
6.45%	6.5%	6.6%	7%	7.01%	7.1%	7.2%	7.25%	7.3%	7.5%	8%		
6.45	0	146	6.6	0	135	7.01	7.1	0	131	7.25	0	0
5002	1	161	5002	1	149	5002	5002	1	143	1	1	1
0	2	176		4	0	2	159	3	157	3	1	1
17	17	192		17	17	17	173	6	171	17	6	6
	23	207		21	21	20	187	20	19	18	18	18
	38	223		35	35	34	201	34	33	31	31	31
	53			49	49	48	215	47	46	43	43	43
	69			64	64	62	229	61	59	56	56	56
	84			78	78	76	243	75	73	68	68	68
	99			92	92	90	256	89	81	81	81	81
	115			107	107	104		102	93	93	93	93
	130			121	121	118		116	106	106	106	106

CONNECTICUT				
5.25%	6%	7%	7.5%	8%
0	198	0	0	0
1	218	1	1	1
2		2	1	3
16		8	7	6
27		24	21	19
46		41	35	33
65		58	49	46
84		74	64	59
103		91	78	73
122		108	92	
141		124	107	
160				
179				

D

DISTRICT OF COLUMBIA					
D.C. 5%	D.C. 5.75%	D.C. 6%	D.C. 6%	D.C. 8%	D.C. 9%
0	5.75	0	0	0	0
1	5002	1	1	1	1
1	0	1	1	1	6
10	8	12	8	12	6
22		17	24	16	16
42		35	41	27	27
82		53	58	39	38
62		71	74	50	49
110		89	91	62	61
		112	108	75	72
				90	83
				112	94

F

FLORIDA					
PANAMA CITY BEACH					
4%	5%	Combined 5.25%	6%	6.2%	7%
0	175	0	5.25	0	6.2
1	209	1	5002	1	5002
5		1		1	
9		9		9	
25		20		16	
50		40		33	
75		60		50	
109		80		66	
125		109		83	
150				109	

G

GEORGIA				
3%	4%	5%	6%	
0	0	0	0	0
1	1	1	1	1
1	1	1	1	1
10	10	10	10	10
35	25	20	20	20
66	50	40	35	35
110	75	60	50	50
	110	80	67	67
		110	85	85
			110	110

H

HAWAII	
4%	
0	0
1	1
1	1
1	1
12	12
37	37

Getting Started

NEW HAMPSHIRE				NEW JERSEY				NEW MEXICO													
Rooms & Meals		Rooms & Meals		3%	3.5%	6%	7%	3.75%	4.25%	4.375%	4.5%	4.875%	5.175%	5.25%	5.375%	5.575%	5.75%				
7%	7%	8%																			
0	129	0	128	0	0	0	150	0	280	0	247	0	239	0	4.875	5.175	0	199	5.375	5.575	5.75
1	143	1	142	1	1	1	164	1	306	1	270	1	1	1	5002	5002	1	217	5002	5002	5002
8	158	8	157	4	1	1	178	6	333	1	294	4	1	1			11				
14	172	35	171	35	41	42	207	13	359	11	317	11	11	11			9				
26	186	35	185	35	41	42	21	40		35	341	34	33	33			28				
39	201	38	200	35	71	71	38	67		58	364	57	55	55			47				
51		50		37	100	100	50	93		82	388	79	78	78			66				
63		62		50	128	72	64	120		105	411	102	100	100			85				
75		74		62	157	88	78	146		129		125	122	122			104				
88		87			185	110	92	173		152		148	144	144			123				
101		100					107	200		176		171	167	167			142				
115		114					135	226		199		194	189	189			161				
								253		223		217	211	211			180				

NEW MEXICO	
6.187%	6.1875%
0	6.1875
1	5002
4	0
9	8
23	
40	
56	
72	
88	
104	
120	
136	
153	

NEW YORK														ERIE		SUFFOLK County				
4%	5%	5.25%	5.75%	6%	6.25%	6.5%	6.75%	7%	7.25%	7.5%	7.5%	8%	8%	8.25%	8.5%					
0	0	5.25	5.75	0	141	0	0	130	6.75	0	121	7.25	0	113	0	105	0	106	8.25	8.5
1	1	5002	5002	1	158	1	1	146	5002	1	135	5002	1	126	1	119	1	118	5002	5002
5	6			7	7	7	1	161		8	149		8	139	10	131	9	131		
12	10			10	10	10	7	176		10	164		10		10	144	10			
33	27			22	22	23	192	20	178	18	17	17	17		17		17			
58	47			38	38	38	207	33	192	31	29	29	29		29		29			
83	67			56	54	53		47	207	45	42	42	42		42		42			
112	87			72	70	69		62		58	55	54	54		54		54			
137	109			88	86	84		76		71	67	67	67		67		67			
				108	103	99		91		85	80	79	79		79		79			
				124	119	115		107		99	92	92	92		92		92			

NORTH CAROLINA							
3%		4%		4.5%		5%	
CHROKEE Reservations							
6%	6%	6%	6%	6%	6%	6%	
0	0	0	188	0	0	0	
1	1	1	211	1	1	1	
4	5	6	233	6	2	2	
9	9	9	255	8	10	8	
35	29	25	277	23	24	24	
70	59	53	299	48	41	41	
116	84	75	322	67	58	58	
149	112	95		85	74	74	
183	137	122		109		91	
216	144	129				108	
	166					124	

NORTH DAKOTA										
3%	4%	4%	5%	5.5%	6%	6.5%	7%	8%		
0	0	0	0	0	182	0	0	170	0	0
1	1	1	1	1	200	1	1	185	1	1
3	5	2	2	2	219	3	2	200	2	3
15	15	15	15	15	15	15	15	216	15	15
33	31	25	20	19	17	31	231	15	15	15
67	51	50	40	37	34	47	29	25	25	25
100	71	75		55	50	62	43	38	38	38
133	100	100		73	67	77	58	50	50	50
166	125	125		91	84	93	72	63	63	63
200				110	108	108	86	75	75	75
				128	124	124	100	88	88	88
				146	139	139	115	100	100	100
				164		154				

OHIO							
5%	5.5%	5.75%	6%	6%	MEIGS Co.	6.25%	
0	0	146	5.75	0	0	134	0
1	1	164	5002	1	1	1	1
2	2	182		2	3	2	2
15	15	200		15	16	15	15
20	18	218		17	17	16	16
40	36			34	34	32	32
	54			50	50		
	72			67	67		
	90			83	83		
	109			100	100		
	127			117	117		

OHIO						
CUYAHOGA Co.						
6.5%	7%	7%	7.75%			
0	123	0	115	0	115	7.75
1	138	1	128	1	128	5002
3	153	3		3		
15	169	15		15		
15	184	15		15		
30	200	28		28		
46	215	42		42		
61	230	57		57		
76		71		71		
92		85		85		
107		100		100		

OKLAHOMA																		
2%	3%	3.25%	4%	4.25%	4.5%	5%	5.25%	6%	6.25%	6.25%	7%	7.25%	7.375%	8%	8.25%	9.25%	10.25%	
0	0	0	323	0	4.25	0	0	5.25	0	0	6.725	0	0	7.375	0	0	0	0
1	1	1	353	1	5002	1	1	5002	1	1	5002	1	1	5002	1	1	1	1
24	16	15	415	12		11	9		1	1		8		6		6	5	4
74	49	46	446	37		33	29		24	23		22		18		18	16	14
	83	76	476			55			41			37		31		30	27	24
	116	107	507			77			58			51		42		42	37	34
		138	538			99						65		54		54	48	43
		169	569			121						79		66		66	59	
		199	599			144						94		78		78	70	
		230										108		90		90	81	
		261										122		103		103	91	
		292																

PENNSYLVANIA		
6%	7%	
0	0	150
1	1	150
1	5	167
10	10	184
17	17	210
34	34	217
50	50	234
67	50	250
84	67	250
110	84	
	110	
	117	
	134	

RHODE ISLAND		
6%	7%	
0	0	149
1	1	164
6	5	178
9	7	192
26	21	207
42	35	221
57	49	235
73	64	249
90	78	264
106	92	
123	107	
140	121	
	135	

SOUTH CAROLINA		
CHARLESTON		
4%	5%	6%
0	0	0
1	1	1
5	6	2
10	10	10
25	20	24
50	40	41
75	60	41
112	80	58
137	109	74
	129	91
		108
		124

SOUTH DAKOTA							
4%	5%	5.5%	6%	6.5%	7%		
0	0	0	190	0	0	149	
1	1	1	210	1	1	176	1
12	10	10		9	7	192	4
37	30	28		26	23	207	7
		46		43	38		21
		64		60	53		35
		82		76	69		49
		100		92	84		64
		118		109	99		78
		136			99		92
		154			115		107
		172			130		121
					146		135

TENNESSEE																							
COUNTY TAX																							
4.5%	5.5%	6%	6.25%	6.5%	6.75%	7%	7.25%	7.5%	7.75%	8%	8%	8.25%	8.5%	8.75%									
0	188	0	154	354	0	0	0	130	0	125	0	121	0	117	0	7.75	0	0	106	8.25	0	99	8.75
1	211	1	172	372	1	1	1	146	1	140	1	1	1	130	1	5002	1	1	118	5002	1	111	5002
1		11	190	390	2	2	2	161	8	155	2	2	2	10	144	2	2	2	2	2	2	2	123
11		10	209		10	10	10	176	10	170	10	10	10	10	158	10	10	10	10	10	10	10	135
33		27	227		24	23	23	192	22	185	21	20	172	19	18	18	18	18	18	18	18	17	147
55		45	245		41																		

TEXAS																				
												HOUSTON (Harris County)								
												DALLAS								
4%	4%	4.125%	4.625%	5%	5.125%	5.25%	5.375%	5.5%	5.625%	6%	6%	6%	6.125%	6.25%	6.25%	6.75%				
0	0	0	206	4.625	0	5.125	0	161	5.375	0	155	0	0	0	6.125	0	6.25	0	125	288
1	1	1	230	5002	1	5002	1	180	5002	1	173	1	1	1	5002	1	5002	1	140	303
1	1	1	254		1		12	199		1	191	1	1	1	1	1	1	3	155	318
12	12	12	278		9		9	219		9	209	8	8	9	8	7	7	8	170	333
37	37	36	303		29		28	238		27	26	24	25	24	23	22	22	185	348	
	62	60	327		49		47		45	44	41	42	41	39	39	37	37	199	362	
	87	84	351		69		66		63	62	58	59	58	55	55	51	51	215	377	
		109	375				85		81	79	71		74	71	71	66	66	229	392	
		133	399				104		99	97	81		91	87	87	81	81	244	407	
		157	424				123		118	115	103		108	103	103	96	96	259	422	
		181					142		137	133	111			119	119	111	111	274	437	

TEXAS					
7%	7.25%	7.5%	7.75%	8%	8.25%
0	107	7.25	0	0	8.25
4	2	5002	1	1	5002
1	1		1	5	
1	1		1	1	
7			6	6	135
21			19	19	148
35			33	32	161
49			46	45	174
64			59	58	187
78			73	70	
92			86	83	

UTAH														
4.75%	5%	5.25%	5.375%	5.5%	5.75%	5.875%	6%	6.125%	6.25%	7%	7.25%			
0	221	0	0	199	0	0	190	5.75	5.875	0	6.125	0	0	7.25
1	242	1	1	219	1	1	209	5002	5002	1	5002	1	1	5002
10	263	1	1	238	1	1			0	2	0	4	2	
31	284	9	9	257	9	9			8	8	8	7	7	
52	305	29	28	276	27	27					24	23	21	
73	326	47	47	295	46	45					41	27	35	
94	347	66	66	314	65	63					58	47	49	
115	368	85	85	333	83	81					74	63	64	
136	389	104	104	352	102	99							78	
157	410	123	123	371	118	118							92	
178		142	142	390	136	136							107	
199		161	161	409	154	154								
		180	180		172	172								

VERMONT			
3%	4%	5%	8%
0	0	0	0
1	1	1	1
4	2	2	0
13	10	10	18
33	25	20	31
66	50	40	43
100		80	56
133		100	68
166		120	81
200		140	93
		100	

VIRGINIA																				
ARLINGTON COUNTY			FAIRFAX			FAIRFAX CITY			HAMPTON		LEESBURG		RICHMOND		ALEXANDRIA		NEWPORT NEWS		RICHMOND	
4%			4.5%			5.5%			7%		7%		7.5%		7.5%		7.5%		8%	
0	214	484	0	0	188	0	149	0	124	0	114	284	0	0	7.5	0	116	0	0	114
1	234	512	1	1	211	1	166	1	144	1	134		1	1	5002	1	122	1	1	114
13	259	537	2	2	233	4	188	1	166	13	149		1	1		1	144	2	5	134
33	284		12	15	255	11	211	11	174	14	159		7	14		11	149	6	14	134
66	314		37	33	277	14	233	24	188	29	184		21	14		16	166	19	34	159
100	334		62	55	299	33	249	33	211	34	184		35	34		33	183	33	44	
133	359		87	77		55	255	55		44	214		49	59		49	188	46	44	
166	384		112	99		77		74		59	214		64	59		55	211	59	59	
200	414		137	122		99		77		74	234		78	84		77		59	59	
	434		144	122		99		99		84	249		92	84		83		59	59	
	459		166	144		122		144		114	259		107	114		93		84	84	
				166		144		144		114						83		84	84	

VIRGINIA											
ROANOKE CITY VA BEACH		NORFOLK CITY		CITY OF RICHMOND							
8.5%		9%		9.5%							
0	99	9	0	99	211	0	89	205	0	89	209
1	112	5002	1	99	233	1	99	1	99	1	99
1	122		6	122	233	1	110	1	109	1	109
11	137		11	122		5	121	9	122	9	122
12	144		33	144		15	131	11	129	11	129
33	162		44	144		26	142	29	144	29	144
37	166		44	166		36	152	33	149	33	149
55	187		55	166		47	163	49	166	49	166
62	188		55	188		57	173	55	169	55	169
77	211		77	188		68	184	69	188	69	188
87			77	211		78	194	77	189	77	189

WASHINGTON															
7%	7.2%	7.3%	7.5%	7.55%	4.125%	7.8%	7.9%	8%	8.1%	8.1%	8.2%	8.7%			
0	0	131	0	129	0	126	0	0	117	8.1	0	115	262	408	0
1	1		1	143	1	139	1	1	129	2	1	128	274	420	1
7	6		6	156	1	153	2	3	151	0	1	140	286	432	1
21	20		19	184	19	179	19	18	18	6	6	152	296	445	5
35	34		33	198	33	193	33	31	31	6	6	154	310	457	17
49	48		47	211	46	206	46	46	44	43	43	191	323	469	28
64	62		61	225	59	217	59	59	57	56	55	203	335	481	
78	76		74	239	73	230	72	72	70	70	67	203	347	493	
92	90		88	252	86	243	85	85	83	83	80	203	359	506	
107	104		102	269	99	256	98	98	92	92	80	203	371		
118	118		115		113	269	111	111	104	104	103	249	384		

WEST VIRGINIA				
2%	3%	4%	5%	6%
0	0	0	0	0
1	1	1	1	1
2	2	1	2	2
25	5	12	5	5
50	35	37	20	16
100	70		40	33
	100			50
	135			67
				84
				100
				116

WISCONSIN			
4%	5%	5.5%	5.6%
0	0	0	190
1	1	1	209
1	1	1	1
12	10	9	8
37	21	27	26
	41	45	44
	61	63	62
	81	81	80
	110	99	98
		118	116
		136	133
		154	
		172	

WYOMING			
3%	4%	5%	6%
0	0	0	0
1	1	1	1
2	2	2	3
24	24	24	24
49	37	29	24
83	62	49	34
116		69	51
149		89	68
		109	84

11. Tax table programming (continued...)

Programming Canadian Tax Tables Procedure


State sales tax calculation data tables for all of the states that make up all Canadian provinces are included on this page. This data is current as of October 30, 1994. Simply find your state or province in the tax tables and input the data shown in its table.

Programming Tax Table

Example 1: Federal tax: 7% (Add-on/Round-off)

Example 2: Ontario 10% (Tax-on-tax/Round off)


MANITOBA/ SASKATCHEWAN	ONTARIO	N.B. & P.E.I.	QUEBEC
6%	7%	8%	9%
6	7	0	9
5002	5002	1	9002
		25	
		31	
		43	
		56	




Assign Tax Table 1

7

Terminate program



NOVA SCOTIA	ONTARIO	QUEBEC
10%	10%	10%
10	10	10
5004	5004	5004




Assign Tax Table 2

(Table 3: 0 3 2 5)

10

Terminate program



• 3 tax tables are used for the following purpose:

- Tax table 1: Used for the federal taxable items.
- Tax table 2: Used for the provincial taxable items.
- Tax table 3: Used for the provincial taxable items for different tax table.

CANADA TAX TABLES

* Must be programmed into Tax Table 2 or 3



CANADA									
* NOVA SCOTIA	* ONTARIO	* QUEBEC	* NEWFOUNDLAND	* ONTARIO	* BRITISH COLUMBIA	* MANITOBA/ SASKATCHEWAN	* ONTARIO	* N.B. & P.E.I.	* QUEBEC
10%	10%	10%	12%	12%	6%	6%	7%	8%	9%
10	10	10	12	0	0	6	7	0	9
5004	5004	5004	5004	1	1	5002	5002	1	9002
				4	2			3	
				25	14			25	
				25	24			25	
				25	41			31	
				29	58			43	
				37	74			56	
				45					
				54					

Important!

Be sure you use the federal sales tax data with your provincial sales tax data. Even if your province use the same tax rate as another province, inputting the wrong data will result incorrect tax calculations.

12. Setting the store telephone number

(This step can be skipped.)



Example:
 (123)456-7890 enter as "1234567890".

Receipt Sample

```

123-
456-7890

12-06-96
1 12-35
   0025

01  •10•00 I
02  •20•00 II
     10 % -
     -2•00 II
     •10•00 I TA
     •0•40 I TX
     •18•00 II TA
     •0•90 II TX


     •29•30 TL
     •50•00 CA AT
     •20•70 CG
       2 No
  
```

Telephone number
 (Adds hyphens automatically.)

Introducing the PCR-360

This part of the manual introduces you to the cash register and provides a general explanation of its various parts.

General guide



Battery compartment

Holds memory backup batteries. (page 8).

Roll paper


You can use the roll paper to print receipts and a journal (page 10 ~ 13).

Printer ink ribbon

Provides ink for printing of registration details on the roll paper (page 81).

Receipt On/Off key

When you are using the printer for receipt printer, you can use this key (in the REG and RF modes only) to turn the printer on and off. If a customer asks for a receipt while receipt printing is turned off by this key, you can issue a post-finalization receipt (page 55).




Note: Instead of the receipt on/off switch, receipt issuance is controlled by this key.

Mode key

There are two types of mode keys: the program key (marked "PGM") and the operator key (marked "OP").

The program key can be used to set the mode switch to any position, while the operator key can select the **REG**, **CAL** and **OFF** position only .




**Program
key**

**Operator
key**

Mode switch

Use the mode keys to change the position of the mode switch and select the mode you want to use.



Mode Switch	Mode Name	Description
Z	RESET	Reads sales data in memory and clears the data.
X	READ	Reads sales data in memory without clearing the data.
CAL	CALCULATOR	Use this mode for calculator.
REG	REGISTER	Use this mode for normal registration.
OFF	POWER OFF	Cash register power switched off.
RF	REFUND	Use this mode to register refund transactions.
PGM	PROGRAM	Use this mode for cash register programming.

Drawer


The drawer opens automatically whenever you finalize a registration and whenever you issue a **READ** or **RESET** report. The drawer will not open if it is locked with the drawer key .

Drawer key

Use the drawer key to lock and unlock the drawer .

When the cash drawer does not open!

In case of power failure or the machine is in malfunction, the cash drawer does not open automatically. Even in these cases, you can open the cash drawer by pulling drawer release lever (see below).



Important!



The drawer will not open, if it is locked with a drawer lock key .

Displays


Main Display

Pop-up display



Department registration





PLU registration



Repeat registration



Totalize operation



① Amount/Quantity

This part of the display shows monetary amounts. It also can be used to show the current date and time.

② Department Number

When you press a department key to register a unit price, the corresponding department number (01 ~ 40: U.S., 01 ~ 10: Canada) appears here.

③ PLU (Sub-Department Number)

When you register a PLU (Sub-Department) item, the corresponding PLU (Sub-Department) number appears here.

④ Number of Repeats

Anytime you perform a repeat registration (page 32), the number of repeats appears here.

Note that only one digit is displayed for the number of repeats. This means that a "5" could mean 5, 15 or even 25 repeats.

⑤ Total/Change Indicators

When the TOTAL indicator (upper segment) is lit, the displayed value is monetary total or subtotal amount. When the CHANGE indicator (lower segment) is lit, the displayed value is the change due.


⑥ Receipt ON/OFF, X, Z indicators (Lowest segment)

Receipt ON/OFF: When the register issues receipts, this indicator is lit. (REG/RF mode only)

X: Indicates X mode

Z: Indicates Z mode


Keyboard (U.S.)



Register Mode

- ① **Paper Feed key**
 Hold this key down to feed paper from the printer.
- ② **Percent key**
 Use this key to register premiums or discounts.
 This key can be changed to Manual tax key.
 Manual tax key: Use this key to register manually entered tax amounts (refer to page 67).
- ③ **Minus key**
 Use this key to input values for subtraction.
- ④ **Post Receipt key**
 Press this key to produce a post-finalization receipt.
- ⑤ **Non-add/No sale key** (U.S.)
 Press this key to open the drawer without registering anything. To print reference number (to identify a personal check, credit card, etc.) during a transaction, press this key after some numerical entries.
- ⑥ **Non-add key** (Canada)
 To print reference number (to identify a personal check, credit card, etc.) during a transaction, press this key after some numerical entries.
- ⑦ **Price key**
 Use this key to register unit prices for sub-department.
- ⑧ **Refund key**
 Use this key to input refund amounts and void certain entries.
- ⑨ **Error Correct/Cancel key**
 Use this key to correct registration errors and to cancel registration of entire transactions.
- ⑩ **Open/Clerk number key**
 It is necessary to select one of these functions.
 Open key: Press this key to temporarily release a limitation on the number of digits that can be input for a unit price.
 Clerk number key: Use this key to sign clerk on and off the register.
- ⑪ **PLU/Sub-department key**
 Use this key to input PLU (sub-department) numbers.
- ⑫ **Multiplication/For/Date/Time key**
 Use this key to input a quantity for a multiplication operation and registration of split sales of packaged items. Between transactions, this key displays the current time and date.
- ⑬ **Clear key**
 Use this key to clear an entry that has not yet been registered.
- ⑭ **Ten key pad**
 Use these keys to input numbers.
- ⑮ **Department keys** (U.S.)
 Department keys (Canada)
 Use these keys to register items to departments.
- ⑯ **Received on Account/Tax Status Shift 1 key**
 Received on Account: Press this key following a numeric entry to register money received for non-sale transactions.
 Tax Shift 1: Press this key without a numeric entry to change the Taxable 1 status of the next item.

Keyboard (Canada)



- 17 Paid Out/Tax Status Shift 2 key**

Paid Out: Press this key following a numeric entry to register money paid out from the drawer.
 Tax Shift 2: Press this key without a numeric entry to change the Taxable 2 status of the next item.
- 18 Charge key**

Use this key to register a charge sales.
- 19 Check key**

Use this key to register a check tender.
- 20 Subtotal key**

Press this key to display and print the current subtotal (includes add-on tax) amount.
- 21 Merchandise Subtotal key**

Press this key to display and print the current item price subtotal (excludes add-on tax) amount.
- 22 Cash Amount Tendered key**

Press this key to register a cash sales.
- 23 No sale key** (Canada)

Press this key to open the drawer without registering anything.
- 24 Receipt On/Off key**

Press this key twice to change the status "receipt issue" or "no receipt." This key is only effective when the "use printer for receipt printer" in the printer control program is selected. In case of "receipt issue", the "RECEIPT ON" indicator is lit.

- 25 Department Shift key** (U.S.)

Press this key to shift the department key number from 1 through 20 to 21 through 40 as follows.

⇒ Dept.1	⇒ Dept.21
⇒ Dept.2	⇒ Dept.22
⇒ Dept.3	⇒ Dept.23
⋮	⋮
⇒ Dept.20	⇒ Dept.40

Calculator Mode

- 2 Percent key**
- 5 Drawer open key** (U.S.)
- 11 Memory recall key**
- 12 Clear key**
- 14 Ten key pad** **0**, **1**, ~ **9**, **00**, **.**
- 15 Arithmetic operation keys** **+**, **-**, **x**, and **÷**
- 22 Equal key**
- 23 Drawer open key** (Canada)

How to read the printouts...

- The journal and receipts are records of all transactions and operations.
- The contents printed on receipts and journal are identical, except the date printing line. (The date line is printed on receipts and reports.)
- You can choose the journal skip function (page 56).
If the journal skip function is selected, the cash register will print the total amount of each transaction, and the details of premium, discount and reduction operations only, without printing department and PLU item registrations on the journal.
- The following items can be skipped on receipts and journal.
 - Time
 - Consecutive number
 - Taxable status
 - Taxable amount

Receipt Sample

12-06-96	Date
1 12-35	Clerk No./Time
1234 0025	Machine No./ Consecutive No.
01 •10•00 I	
02 •20•00 II	
10 % -	
-2•00 II	
•10•00 I TA	
•0•40 I TX	
•18•00 II TA	
•0•90 II TX	
•29•30 TL	
•50•00 CA AT	
•20•70 CG	
2 No	Item counter No. of item sold

Journal Sample (Item lines Included)

12-06-96	
1 12-35	
1234 0025	
01 •10•00 I	
02 •20•00 II	
10 % -	
-2•00 II	
•10•00 I TA	
•0•40 I TX	
•18•00 II TA	
•0•90 II TX	
•29•30 TL	
•50•00 CA AT	
•20•70 CG	
2 No	

Journal Sample (Item lines Skipped)


1 12-35	
1234 0025	
10 % -	
-2•00 II	
•10•00 I TA	
•0•40 I TX	
•18•00 II TA	
•0•90 II TX	
•29•30 TL	
•50•00 CA AT	
•20•70 CG	
2 No	

In the operation examples contained in this manual, the print samples are what would be produced if the roll paper is being used for receipts. They are not actual size. Actual receipts are 58 mm wide. Also, all sample receipts and journals are printout images.

How to Use Your Cash Register...

The following describes the general procedure you should use in order to get the most out of your cash register.

BEFORE business hours...




- Check to make sure that the cash register is plugged in securely. Page 10
- Check to make sure there is enough paper left on the roll. Page 11
- Read the financial totals to confirm that they are all zero. Page 72
- Check the date and time. Page 30

DURING business hours...

- Register transactions. Page 31
- Periodically read totals. Page 71



AFTER business hours...




- Reset the daily totals. Page 53
- Remove the journal. Page 82
- Empty the cash drawer and leave it open. Page 23
- Take the cash and journal to the office.





Basic Operations and Setups

Displaying the time and date






You can show the time or date on the display of the cash register whenever there is no registration being made.



To display and clear the time




OPERATION	DISPLAY
 Time appears on the display	 Hour Minutes (24-hour system)
 Clears the time display	 Receipt On Indicator


To display and clear the date

OPERATION	DISPLAY
 Date appears on the display	 (Time displayed first)
	 Month Date Year
 Clears the date display	 Receipt On Indicator



Preparing coins for change

You can use the following procedure to open the drawer without registering an item. This operation must be performed out of a sale.

(You can use  key instead of  () key. See page 49.)



Opening the drawer without a sale


OPERATION	RECEIPT
	

• For Canada, press  key instead of  key.

Preparing and using department keys

Registering department keys

The following examples show how you can use the department keys in various types of registrations.



Single Item Sale

Example 1

Item	Unit Price	\$1.00
	Quantity	1
	Dept.	1
	Taxable	No
Payment	Cash	\$1.00

OPERATION

1 00
Unit price

+ 1
Department

CA/AMT
=/TEND

RECEIPT

```

12-06-96  --- Date
08-40    --- Time
0002     --- Consecutive No.

01      • 1.00  --- Department No./
          • 1.00 CA --- Unit price
    
```

Example 2 (only for U.S.)

Item	Unit Price	\$20.00
	Quantity	1
	Dept.	21
	Taxable	No
Payment	Cash	\$20.00

OPERATION

2 0 00 **DEPT** **21**
Designating from 21 to 40
department, press **SHIFT** first.

CA/AMT
=/TEND

RECEIPT

```

12-06-96
08-50
0003

21      • 20.00
          • 20.00 CA
    
```

Example 3

Item	Unit Price	\$3.00
	Quantity	1
	Dept.	1
	Taxable	1
Payment	Cash	\$3.12

OPERATION

RC **T/S1** **3 00** **+ 1**
Shifting non-taxable dept. to
taxable by depressing **RC**, **PD**
before numerics.

CA/AMT
=/TEND

RECEIPT

```

12-06-96
09-00
0004

01      • 3.00 I  --- Tax status
          • 3.00 I TA --- Taxable Amount 1
          • 0.12 I TX --- Tax 1
          • 3.12 CA
    
```

Basic Operations and Setups

Repeat

	Unit Price	\$1.50
Item	Quantity	3
	Dept.	1
	Taxable	No
Payment	Cash	\$10.00

OPERATION

1 5 0 **+ 1**
+ 1
+ 1
 SUB TOTAL
1 0 00 CA/AMT TEND

RECEIPT

```

12-06-96
09-10
0005

01  • 1.50
01  • 1.50
01  • 1.50

      • 4.50  TL
      • 10.00 CA AT
      • 5.50  CG
  
```

Repeat
Repeat

Multiplication

	Unit Price	\$1.00
Item	Quantity	12.5
	Dept.	1
	Taxable	No
Payment	Cash	\$20.00

OPERATION

1 2 . 5 X/FOR DATE TIME
 Quantity
 (4-digit integer/2-digit decimal)
1 00 **+ 1**
 SUB TOTAL
2 0 00 CA/AMT TEND

RECEIPT

```

12-06-96
09-20
0006

12.5 X
• 1.00 @
01 • 12.50

      • 12.50  TL
      • 20.00 CA AT
      • 7.50  CG
  
```

Quantity
Unit Price

Split Sales of Packaged Items

	Unit Price	4 for \$10.00
Item	Quantity	3
	Dept.	1
	Taxable	No
Payment	Cash	\$10.00

OPERATION

3 X/FOR DATE TIME
 Quantity being purchased
 (4-digit integer/2-digit decimal)
4 X/FOR DATE TIME
 Package quantity
 (4-digit integer/2-digit decimal)
1 0 00 **+ 1**
 Package price
 SUB TOTAL
1 0 00 CA/AMT TEND

RECEIPT

```

12-06-96
09-30
0007




      3 X
      4
01 • 10.00 @
      • 7.50

      • 7.50  TL
      • 10.00 CA AT
      • 2.50  CG
  
```

Quantity
Package quantity
Unit Price

Programming department keys

To program a unit price for each department.



Basic Operations and Setups

Basic Operations and Setups



To program the tax calculation status for each department.

Tax calculation status

This specification defines which tax table should be used for automatic tax calculation. See page 16 for information on setting up the tax tables.

Programming procedure

U.S.





Note: Tax symbols

- I : Taxable 1
- II : Taxable 2
- III : Taxable 1 and 2

Tax status for the departments are initialized as follows:

- Department 1 ~ 10: Tax table 1 and 2,
- Department 11 ~ 40: No tax calculation.

Canada




Note: Tax symbols

- I : Taxable 1
- II : Taxable 1 and 2
- III : Taxable 1 and 3
- * : Taxable 1, 2 and 3

Tax status for the departments are initialized as follows:

- Department 1 ~ 5: Tax table 1 and 2,
- Department 6 ~ 10: No tax calculation.

Registering department keys by programming data



Preset Price

OPERATION

RECEIPT

	Unit Price	(\$1.00) _{preset}
Item	Quantity	1
	Dept.	2
	Taxable	No
Payment	Cash	\$1.00

2
CA/AMT
= TEND

```

12-06-96 --- Date
09-40 --- Time
0008 --- Consecutive No.
02 • 1.00 --- Department No./
                Unit price
                • 1.00 CA
    
```

Preset Tax Status

OPERATION

RECEIPT

Item 1	Unit Price	(\$2.00) _{preset}
	Quantity	5
	Dept.	3
	Taxable	(1) _{preset}
Item 2	Unit Price	(\$2.00) _{preset}
	Quantity	1
	Dept.	3
	Taxable	No
Payment	Cash	\$20.00

5 X/ FOR
/ DATE
/ TIME
3
x
PC
/ T/S1 x **3**
SUB
TOTAL
2 0 00 CA/AMT
= TEND

```

12-06-96
09-50
0009
5 X
• 2.00 @ --- Tax status
03 • 10.00 I --- Taxable Amount 1
03 • 2.00 --- Tax 1
• 10.00 I TA
• 0.40 I TX
• 12.40 TL
• 20.00 CA AT
• 7.60 CG
    
```

Preparing and using PLUs

This section describes how to prepare and use PLUs.


CAUTION:

Before you use PLUs, you should first tell the cash register how it should handle the registration.


Programming PLUs

To program a unit price for each PLU

U.S.





Canada





To program tax calculation status for each PLU

U.S.



All PLUs are initialized as no tax calculation.

Canada




All PLUs are initialized as no tax calculation.

Basic Operations and Setups

Registering PLUs

The following examples show how you can use PLUs in various types of registrations.

Registering by Sub-department, see the "Convenient Operations and Setups" on page 61.



PLU Single-Item-Sale

OPERATION

RECEIPT

	Unit Price	(\$2.50) _{preset}
Item	Quantity	1
	PLU	14
	Taxable	(2) _{preset}
Payment	Cash	\$3.00

1 4
PLU code

PLU/S.DEPT

SUB TOTAL

3 00 **CA/AMT**
=/TEND

```

12-06-96
10-00
0010
014  •2.50 II
•2.50 II TA
•0.13 II TX
•2.63 TL
•3.00 CA AT
•0.37 CG
    
```

PLU No./Unit price

PLU Repeat

OPERATION

RECEIPT

	Unit Price	(\$2.50) _{preset}
Item	Quantity	3
	PLU	14
	Taxable	(2) _{preset}
Payment	Cash	\$10.00

1 4 **PLU/S.DEPT**

PLU/S.DEPT

PLU/S.DEPT

SUB TOTAL

1 0 00 **CA/AMT**
=/TEND

```

12-06-96
10-10
0011
014  •2.50 II
014  •2.50 II
014  •2.50 II
•7.50 II TA
•0.38 II TX
•7.88 TL
•10.00 CA AT
•2.22 CG
    
```

PLU Multiplication

OPERATION

RECEIPT

	Unit Price	(\$1.20) _{preset}
Item	Quantity	15
	PLU	2
	Taxable	(2) _{preset}
Payment	Cash	\$20.00

1 5 **X/FOR**
DATE
TIME

Quantity
(4-digit integer/2-digit decimal)

2 **PLU/S.DEPT**

SUB TOTAL

2 0 00 **CA/AMT**
=/TEND

```

12-06-96
10-20
0012
15 X
•1.20 @
002 •18.00 II
•18.00 II TA
•0.90 II TX
•18.90 TL
•20.00 CA AT
•1.10 CG
    
```

PLU Split Sales of Packaged item

OPERATION

RECEIPT

	Unit Price	(5for\$20.00) _{preset}
Item	Quantity	3
	PLU	28
	Taxable	(2) _{preset}
Payment	Cash	\$15.00

3 FOR
DATE
TIME
Quantity being purchased
(4-digit integer/2-digit decimal)

5 FOR
DATE
TIME
Package quantity
(4-digit integer/2-digit decimal)

2 8 PLU/
S.DEPT

SUB
TOTAL

1 5 00 CA/AMT
=/TEND

```

12-06-96
  10-30
   0013

      3 X
      5
•20•00 @
028 •12•00 II
      •12•00 II TA
      •0•60 II TX

      •12•60 TL
      •15•00 CA AT
      •2•40 CG
    
```



Preparing and using discounts

This section describes how to prepare and register discount.

Programming discounts

You can use the [%] key to register discounts (percentage decreases). The more detailed informations about the discount (and premium) are described in the "Registering discounts and premiums" section in the "Convenient Operations and setups" chapter on page 65.

To program a rate to the [%] key




Tax status for the [%] key is initialized as tax 1 and 2. (U.S.)

Tax status for the [%] key is initialized as tax 1, 2 and 3. (Canada)

Registering discounts

The following example shows how you can use the [%] key in various types of registration.



Discount for Items and subtotals

OPERATION

RECEIPT

Item 1	Unit Price	\$5.00
	Quantity	1
	Dept.	1
	Taxable	(1) _{preset}
Item 2	Unit Price	(\$10.00) _{preset}
	Quantity	1
	PLU	16
	Taxable	(2) _{preset}
Discount	Rate	(5%) _{preset}
Subtotal	Rate	3.5%
discount	Taxable	1 and 2
Payment	Cash	\$15.00

5 00 + 1
1 6 PLU/
S.DEPT
[%]

Applies the preset discount rate to the last item registered.

For this operation, hit this key instead of ^{SUB}TOTAL.

3 . 5 [%]

The input value takes priority of the preset value.

1 5 00 ^{SUB}TOTAL
CA/AMT
= / TEND

```

12-06-96
 10-40
 0014

01  .500 I
016 .1000 II
    5 % -
    -0.50 II
    .14.50 ST
    3.5 % -
    -0.51 III
    .4.82 I TA
    .0.19 I TX
    .9.17 II TA
    .0.46 II TX

.14.64 TL
.15.00 CA AT
.0.36 CG
    
```

- You can manually input rates up to 4 digits long (0.01% to 99.99%).

Taxable status of the [%] key

- Whenever you perform a discount operation on the last item registered, the tax calculation for discount amount is performed in accordance with the tax status programmed for that item.
- Whenever you perform a discount operation on a subtotal amount, the tax calculation for the subtotal amount is performed in accordance with the tax status programmed for the [%] key.


Preparing and using reductions

This section describes how to prepare and register reductions.

Programming for reductions

You can use the key to reduce single items or subtotal amounts. The following procedure lets you program the tax calculation method for the key.

To program tax calculation status.




Tax status for the key is initialized as no tax calculation.

Taxable status of the key

The tax calculation for the reduction amount is performed in accordance with the tax status programmed for the key, regardless of whether the reduction is performed on the last item registered or a subtotal amount.

Registering reductions

The following examples show how you can use the key in various types of registration.



Reduction for Items

OPERATION

RECEIPT

Item 1	Unit Price	\$5.00
	Quantity	1
	Dept.	1
Reduction	Taxable	(1) _{preset}
	Amount	\$0.25
Item 2	Unit Price	(\$6.00) _{preset}
	Quantity	1
	PLU	45
Reduction	Taxable	(1) _{preset}
	Amount	\$0.50
Payment	Cash	\$11.00

5 00 + 1
 2 5 -
 Reduces the last amount registered by the value input.
 4 5 PLU/S.DEPT
 5 0 -
 SUB TOTAL
 1 1 00 CA/AMT =/TEND

```

12-06-96
  10-50
   0015

01    • 5.00 I
      - 0.25 I
045   • 6.00 I
      - 0.50 I
      • 10.25 I TA
      • 0.41 I TX

      • 10.66 TL
      • 11.00 CA AT
      • 0.34 CG
  
```

- You can manually input reduction values up to 7 digits long.
- The amount you input for the reduction is neither subtracted from the department nor PLU totalizer.

Reduction for Subtotal

OPERATION

RECEIPT

Item 1	Unit Price	\$3.00
	Quantity	1
	Dept.	1
Reduction	Taxable	(1) _{preset}
	Amount	\$0.75
Item 2	Unit Price	\$4.00
	Quantity	1
	Dept.	2
Reduction	Taxable	(2) _{preset}
	Amount	\$0.75
Subtotal	Amount	\$0.75
Reduction	Taxable	(No) _{preset}
Payment	Cash	\$7.00

3 00 + 1
 4 00 - 2
 SUB TOTAL
 7 5 -
 Reduces the subtotal by the value input here.
 SUB TOTAL
 7 00 CA/AMT =/TEND

```


12-06-96
  11-00
   0016

01    • 3.00 I
02    • 4.00 II
      - 0.75
      • 3.00 I TA
      • 0.12 I TX
      • 4.00 II TA
      • 0.20 II TX

      • 6.57 TL
      • 7.00 CA AT
      • 0.43 CG
  
```

Calculating the merchandise subtotal

Use the operation shown below to calculate the merchandise subtotal, which includes the actual cost of the merchandise only without the add-on tax.




Calculation merchandise subtotal

	OPERATION	DISPLAY
Item 1	Unit Price \$1.00	01 100
	Quantity 1	02 200
	Dept. 1	03 300
	Taxable (1) _{preset}	TOTAL n _ 6.00
Item 2	Unit Price \$2.00	Calculates the merchandise subtotal.
	Quantity 1	TOTAL n _ 6.26
	Dept. 2	Calculates the subtotal (with add-on tax).
Taxable (2) _{preset}	CHANGE n _ 3.74	
Item 3	Unit Price \$3.00	RECEIPT
	Quantity 1	
	Dept. 3	
Taxable (1) _{preset}		
Payment Cash \$10.00		

- For a partial tender operation, you should press the key instead of the key.

Shifting the taxable status of an item

By pressing "Tax Shift" key, you can shift the taxable status of an item.



Calculation merchandise subtotal

OPERATION

RECEIPT

Item 1	Unit Price	\$4.00
	Quantity	1
	Dept.	1
	Taxable	(2) _{preset}
Item 2	Unit Price	\$2.00
	Quantity	1
	Dept.	2
	Taxable	(No) → 1
Item 3	Unit Price	\$6.00
	Quantity	1
	Dept.	3
	Taxable	(1) → 1, 2
Item 4	Unit Price	\$7.00
	Quantity	1
	Dept.	4
	Taxable	(2) → No
Payment	Cash	\$20.00

4 00 + 1
RC/T/S1

2 00 - 2
Pressing RC/T/S1 changes the tax status from Non-taxable to Taxable 1

6 00 x 3
Pressing PD/T/S2 changes the tax status from Taxable 1 to Taxable 1, 2

7 00 ÷ 4
Pressing PD/T/S2 changes the tax status from Taxable 2 to Non-taxable

2 0 00 =/CA/AMT/TEND
SUB/TOTAL

```

12-06-96
 11-20
 0018

01  • 4.00 II
02  • 2.00 I
03  • 6.00 III
04  • 7.00
      • 8.00 I TA
      • 0.32 I TX
      • 10.00 II TA
      • 0.50 II TX

      • 19.82 TL
      • 20.00 CA AT
      • 0.18 CG
    
```


Important!

- To change the tax status of the next item to be registered, be sure to press RC/T/S1 , PD/T/S2 without inputting any value.
- If the last item registered is programmed as non-taxable, a premium/discount (P key) operation on this item is always non-taxable.

In this case, you cannot manually change the tax status to Taxable 1 or 2 by pressing RC/T/S1 , PD/T/S2 keys.

Registering charge and check payments

The following examples show how to register charges and payments by check.



Check

OPERATION

RECEIPT

Item 1	Unit Price	\$10.00
	Quantity	1
	Dept.	1
	Taxable	(1) _{preset}
Payment	Check	\$20.00

1 0 00 + 1
SUB TOTAL
2 0 00 CHK

```

12-06-96
 11-30
  0019
01  •10•00 I
     •10•00 I TA
     •0•40 I TX

     •10•40 TL
     •20•00 CK
     •9•60 CG
    
```

Charge

OPERATION

RECEIPT

Item 1	Unit Price	\$15.00
	Quantity	1
	Dept.	4
	Taxable	(2) _{preset}
Reference	Number	123456
Payment	Charge	\$15.75

1 5 00 ÷ 4
SUB TOTAL
*1 1 2 3 4 5 6 #/NS
CH
*1 For Canada, # instead of #/NS.

```

12-06-96
 11-40
  0020
04  •15•00 II
     123456 # Reference No.
     •15•00 II TA
     •0•75 II TX

     •15•75 CH
    
```

Mixed tender (cash, charge and check)

OPERATION

RECEIPT

Item 1	Unit Price	\$55.00
	Quantity	1
	Dept.	4
	Taxable	(2) _{preset}
Payment	Check	\$30.00
	Cash	\$3.00
	Charge	\$24.75

5 5 00 ÷ 4
SUB TOTAL
3 0 00 CHK
3 00 CA/AMT TEND
CH


```

12-06-96
 11-50
  0021
04  •55•00 II
     •55•00 II TA
     •2•75 II TX

     •57•75 TL
     •30•00 CK
     •3•00 CA
     •24•75 CH
    
```

Registering returned goods in the REG mode

The following example shows how to use the **RF** key in the REG mode to register goods returned by customers.



OPERATION

RECEIPT

Item 1	Unit Price	\$2.35
	Quantity	1
	Dept.	1
	Taxable	(1) _{preset}
Item 2	Unit Price	\$2.00
	Quantity	1
	Dept.	2
	Taxable	(2) _{preset}
Item 3	Unit Price	(\$1.20) _{preset}
	Quantity	1
	PLU	1
	Taxable	(2) _{preset}
Returned Item 1	Unit Price	\$2.35
	Quantity	1
	Dept.	1
	Taxable	1
Returned Item 3	Unit Price	(\$1.20) _{preset}
	Quantity	1
	PLU	1
	Taxable	2
Payment	Cash	\$2.10

2 3 5 + 1

2 00 - 2

1 PLU/
S.DEPT

RF

2 3 5 + 1

Pressing **RF** specifies that the next item registered is a return.

RF

1 PLU/
S.DEPT

You have to press **RF** before registering each returned item.

SUB
TOTAL

CA/AMT
= /TEND

```


12-06-96
 12-00
 0022

01  .2.35 I
02  .2.00 II
001 .1.20 II
..... RF
01  -2.35 I
..... RF
001 -1.20 II
     .2.00 II TA
     .0.10 II TX

.2.10 CA
    
```


Registering money received on account

The following example shows how to register money received on account. This registration must be performed out of a sale.



OPERATION

Received Amount	\$700.00
-----------------	----------

7 00 00 RC T/S1
Amount can be up to 8 digits.


RECEIPT

```

12-06-96
  12-30
   0025
• 700.00 RC
    
```

Registering money paid out

The following example shows how to register money paid out from the register. This registration must be performed out of a sale.



OPERATION

Paid Out Amount	\$1.50
-----------------	--------

1 5 0 PD T/S2
Amount can be up to 8 digits.

RECEIPT


```

12-06-96
  12-40
   0026
• 1.50 PD
    
```

Making corrections in a registration

There are three techniques you can use to make corrections in a registration.

- To correct an item that you have input but not yet registered.
- To correct the last item you have input and registered.
- To cancel all items in a transaction.



Mode Switch

To correct an item you have input but not yet registered

OPERATION

RECEIPT

<p>2 00 C C/C</p> <p>1 00 + 1</p> <p>1 2 X/FOR DATE TIME</p> <p>1 1 X/FOR DATE TIME</p> <p>2 00 _ 2</p> <p>2 C C/C</p> <p>3 PLU/ S.DEPT</p> <p>1 5 PLU/ S.DEPT</p> <p>6 00 C C/C</p> <p>1 5 PLU/ S.DEPT</p> <p>Enter Sub-department No. again.</p> <p>1 0 00 PRICE</p> <p>SUB TOTAL</p> <p>1 0 00 C C/C</p> <p>1 5 00 CA/AMT = /TEND</p> <p>CH</p>	<p>Correction of unit price</p> <p>Correction of quantity</p> <p>Correction of PLU No.</p> <p>Correction of Sub-department unit price (See page 61 for registering)</p> <p>Correction of partial tender amount</p>	<pre> 12-06-96 12-50 0027 01 • 1.00 I 11 X • 2.00 @ 02 • 22.00 II 003 • 1.30 I 015 • 10.00 I • 12.30 I TA • 0.49 I TX • 22.00 II TA • 1.10 II TX • 35.89 TL • 15.00 CA AT • 20.89 CH </pre>
---	--	---

To correct an item you have input and registered

OPERATION

RECEIPT

- 1 00 + 1
- 2 00 - 2
- 2
- ERR CORR. CANCEL
- Clearance
- 2 PLU/ S.DEPT
- ERR CORR. CANCEL
- Correction of PLU
- 5 PLU/ S.DEPT
- 1 5 PLU/ S.DEPT
- 6 00 PRICE
- ERR CORR. CANCEL
- Correction of Sub-department
- 1 5 PLU/ S.DEPT
- 1 0 00 PRICE
- 8 X/FOR DATE TIME
- 4 00 ÷ 4
- ERR CORR. CANCEL
- Correction of Quantity
- 6 X/FOR DATE TIME
- 4 00 ÷ 4
- MD ST
- 5 0 %
- ERR CORR. CANCEL
- Correction of Discount
- MD ST
- 5 %
- RF 2 00 - 2
- ERR CORR. CANCEL
- Correction of Refund item
- RF 2 2 0 - 2
- SUB TOTAL
- 3 0 00 CA/AMT TEND
- ERR CORR. CANCEL
- Correction of Partial tender
- 1 5 00 CA/AMT TEND
- CH

12-06-96
13-00
0028
01 •1.00 I
02 •2.00 II
02 •2.00 II
-2.00 VD
002 •1.20 II
-1.20 VD
005 •1.50 I
015 •6.00 I
-6.00 VD
015 •10.00 I
8 X
•4.00 @
04 •32.00 II
-32.00 VD
6 X
•4.00 @
04 •24.00 II
•38.50 ST
50 % -
-19.25 III
•19.25 VD
•38.50 ST
5 % -
-1.93 III
..... RF
02 -2.00 II
•2.00 VD
..... RF
02 -2.20 II
•11.87 I TA
•0.47 I TX
•22.50 II TA
•1.13 II TX
•35.97 TL
•30.00 CA
-30.00 VD
•15.00 CA
•20.97 CH

Basic Operations and Setups

To cancel all items in a transaction


OPERATION



Pressing key is necessary to cancel the transaction.



RECEIPT



Important!


- Note that the number of items included in the transaction to be cancelled is limited (12 ~ 15 items), depending on the complexity of the transaction. If you try to cancel a transaction that exceeds the limit, an error occurs.

In case of occurrence of this error, register these items in the RF mode.

- You can program the cash register that this cancel operation is not allowed.

No sale registration


You can use the following procedure to open the drawer without registering a sale. This operation must be performed out of a sale.



OPERATION



RECEIPT




*1 For Canada, press instead of key.

Printing the Daily sales RESET report

This report shows daily sales totals.

OPERATION

REPORT



Mode Switch



12-06-96	—	Date
13-30	—	Time
0031	—	Consecutive No.
000 0001Z	—	Report code/RESET counter/ RESET symbol
01 15	—	Department No./No. of items* ¹
•339•50	—	
02 19	—	Department amount* ¹
•62•70	—	
03 31	—	Non-link department No. of items
•139•10	—	
04 23	—	Non-link department amount
•94•90	—	
00 253	—	Gross No. of items
•1146•90 TL	—	Gross sales
8 No	—	Subtraction count
•3•00 -	—	Subtraction amount
10 No	—	Premium/Discount count
•4•62% -	—	Premium/Discount amount

•732•56 I	TA	—	Taxable amount 1* ²
•56•80 I	TX	—	Tax amount 1* ²
•409•72 II	TA	—	Taxable amount 2* ²
•21•55 II	TX	—	Tax amount 2* ²
•272•50 III	TA	—	Taxable amount 3 (Canada only)* ²
•21•55 III	TX	—	Tax amount 3 (Canada only)* ²
100 No	—	—	No. of customers
•1217•63 NT	—	—	Net amount
81 No	—	—	Cash sales count
•836•86 CA	—	—	Cash sales amount
10 No	—	—	Charge sales count
•197•17 CH	—	—	Charge sales amount
9 No	—	—	Check sales count
•183•60 CK	—	—	Check sales amount
2 No	—	—	Received on Account count
•78•00 RC	—	—	Received on Account amount
1 No	—	—	Paid out count
•6•80 PD	—	—	Paid out amount
10 No	—	—	Error correction count
•12•76 VD	—	—	Cancellation count
2 No	—	—	Refund key count* ³
•108•52 * VD	—	—	Refund mode operation count* ³
7 No	—	—	Refund mode operation amount* ³
•27•79 RF	—	—	Refund mode operation amount* ³
2 No	—	—	No sale count
•3•74 * RF	—	—	No sale count
5 #	—	—	No sale count
•908•06 CA	#	—	Cash in drawer amount
•197•17 CH	#	—	Charge in drawer amount
•183•60 CK	—	—	Check in drawer amount
•000000	—	—	Non-resettable
001217•63	—	—	grand-sales total

*¹ Zero totaled departments (the amount and item numbers are both zero) are not printed.

*² Taxable amount and tax amount are printed only the corresponding tax table is programmed.

*³ These items can be skipped by programming.


Convenient Operations and Setups

This section describes more sophisticated setups and operations that you can use to suit the needs of your retail environment.

Clerk control function Post-finalization receipt format General Printing control (receipt/journal/report) Compulsory Machine features

About the clerk control function

To keep track of the registrations performed by different clerks, specify the clerk control function. In case of selecting the clerk control function, signing on operation is necessary before registering, programming or issuing reports.



Clerk sign on


OPERATION

Signing clerk 1 on:	1	➔	OPEN/ CLK #
Signing clerk 2 on:	2	➔	OPEN/ CLK #
	⋮		
Signing clerk 10 on:	1 0	➔	OPEN/ CLK #

Important!

- Once you select the clerk control function, the error code "E08" appears on the display whenever you try to perform a registration, a READ/RESET operation without signing on.
- You can choose either the clerk key function or the open key function.
- The signed on clerk is also identified on the receipt/journal.

Printing Sample



Clerk sign off

OPERATION

Signing clerk off:	0	➔	OPEN/ CLK #
--------------------	----------	---	----------------

- The current clerk is also signed off whenever you set the Mode Switch to OFF position.

About post-finalization receipt

You can issue a receipt even if in no receipt mode.

The post-finalization receipt lets you issue a receipt after finalization of the transaction.


Note that all of the following conditions must be satisfied.

- The option "print receipts" is selected.
- The receipt issuance status must be OFF.
- The transaction must be finalized in the REG or RF mode using the $\boxed{\text{CA/AMT}} \boxed{=}$ $\boxed{\text{TEND}}$, $\boxed{\text{CH}}$ or $\boxed{\text{CHK}}$ key.

Post-finalization receipt Example

You can program the cash register to print the transaction total only (below Total format) or full details (below Detailed format) on the post-finalization receipt.

Note that if the transaction contains more than 26 lines (including receipt header), the cash register prints in a Total format regardless of your programming.



OPERATION

RECEIPT

Item 1	Unit Price	\$10.00
	Quantity	1
	Dept.	1
	Taxable	1
Item 2	Unit Price	\$20.00
	Quantity	1
	Dept.	2
Payment	Cash	\$31.40

$\boxed{1} \boxed{0} \boxed{00} \boxed{+} \boxed{1}$
 $\boxed{2} \boxed{0} \boxed{00} \boxed{-} \boxed{2}$
 $\boxed{4} \boxed{0} \boxed{00} \boxed{=}$ $\boxed{\text{CA/AMT}} \boxed{\text{TEND}}$
 $\boxed{\text{SUB TOTAL}}$
 $\boxed{\text{POST RECEIPT}}$

Receipt is not issued

Post-finalization receipt is issued.

If "Automatic issue" is selected, no need to press $\boxed{\text{POST RECEIPT}}$ key.

Total format

```

12-06-96
 1 13-40
    0033

• 31 • 40 CA
    
```

Detailed format

```

12-06-96
 1 13-45
    0034

01 • 10 • 00 I
02 • 20 • 00 II
   • 10 • 00 I TA
   • 0 • 40 I TX
   • 20 • 00 II TA
   • 1 • 00 II TX

• 31 • 40 CA
    
```

Important!


- You can issue only one post-finalization receipt per transaction.

Convenient Operations and Setups

Programming general printing control

About the contents of general printing control


The following points are the contents of general printing control.

- Print/Not print a subtotal line on receipt/journal whenever the  key is pressed.
- Feed/Non feed receipt/journal one line before finalization.
- Print/Skip the date on journal.
- Print/Skip item lines on journal. (JOURNAL SKIP)
- Print/Skip taxable amount subtotal of each transaction.
- Print/Skip taxable status symbols on receipt/journal.
- Print/Skip item counter (No. of item sold) line.
- Print/Skip the current time on receipt/journal.
- Print/Skip the consecutive number on receipt/journal in REG/RF modes.
- Print receipt/Print journal (If use 2-ply paper, select "Print receipt".)
- Issue post receipt by Finalize key (automatic issue)/by Post receipt key (manual issue).
- Detail format/Total format in the post receipt.

Programming procedure

default

Print/Non print a subtotal line whenever the key is pressed.	a	Non print = 0 Print = 1	<input type="checkbox"/> (a+b+c)
Feed/Non feed one line before finalization.	b	Feed = 0 Non feed = 2	
Print/Skip the date. (effective, if "Print journal" is selected)	c	Skip = 0 Print = 4	
Print/Skip item lines. (effective, if "Print journal" is selected)	d	Print = 0 Skip = 1	<input type="checkbox"/> (d+e+f)
Print/Skip taxable amount subtotal of each transaction.	e	Print = 0 Skip = 2	
Print/Skip taxable status symbols.	f	Print = 0 Skip = 4	
Print/Skip item counter line.	g	Skip = 0 Print = 1	<input type="checkbox"/> (g+h+i)
Print/Skip the current time.	h	Print = 0 Skip = 2	
Print/Skip the consecutive number.	i	Print = 0 Skip = 4	
Print receipt/Print journal	j	Receipt = 0 Journal = 1	<input type="checkbox"/> (j+k+l)
Issue post-receipt by Finalize key (automatic issue) /Post receipt key (manual issue)	k	Manual = 0 Automatic = 2	
Detail format/Total format in the post-receipt.	l	Detail = 0 Total = 4	



Mode Switch



Programming compulsory and clerk control function

About compulsory, clerk control function...

The following procedure lets you program a number of functions.


- Use **OPEN/CLK#** key as "Clerk" key/"Open" key.*¹
- Assign "00"key/Assign "000" key.
- Reset/Not reset (to 0001) the consecutive number when the Daily RESET report is issued.
- Required/Not required to input the cash in drawer amount before the daily READ/RESET report. (MONEY DECLARATION)
- Prohibit/Allow the cancel operation.
- Force **SUB/TOTAL** key operation before finalization.
- Clear the key buffer when the transaction is terminated.
- Display Hour/Minute/Second or Hour/Minute on time display.

*¹ Effective only after all RESET reports are issued.

Programming procedure

default

Use "Clerk"function/Use "Open" function	a	Open = 0 Clerk = 1	<input type="checkbox"/>
Assign "00" key/Assign "000" key	b	"00" = 0 "000" = 4	<input type="checkbox"/> (a+b)
Reset/Not reset the consecutive number	c	Reset = 0 Non reset = 2	<input type="checkbox"/>
Prohibit/Allow the cancel operation.	d	Allow = 0 Prohibit = 4	<input type="checkbox"/> (c+d)
Force SUB/TOTAL key operation before a finalization	e	No = 0 Compulsory = 2	<input type="checkbox"/>
Required/Not required to input the cash in drawer amount before the Daily report	f	Not required = 0 Required = 4	<input type="checkbox"/> (e+f)
Clear the key buffer when the transaction is terminated	g	Not clear = 0 Clear = 1	<input type="checkbox"/>
Display "seconds" during time display.	h	Suppress = 0 Display = 4	<input type="checkbox"/> (g+h)



Convenient Operations and Setups

Convenient Operations and Setups

Programming READ/RESET report printing control

About READ/RESET printing control


The following procedure lets you program a number of functions.

- Print/Skip the RF mode and RF key totals and counters on the daily and periodic report.
- Print/Skip the grand total on the daily reset report.

Programming READ/RESET printing control



default

Print/Skip RF mode and RF key totals on the daily and periodic report.	a	Print = 0 Skip = 1	<input type="checkbox"/> (a+b)
Print/Skip the grand total on the daily reset report.	b	Print = 0 Skip = 2	




Setting a store/machine number

You can set a 4-digit machine number to identify your machine, the machine number is printed on receipts/journal for each transaction.



Example: 0 0 0 1 to 9 9 9 9, 0 0 0 0 means no machine number.




Setting/Editing the store telephone number

You can program 4 lines of maximum 14 digits of unique number of your store, such as telephone number, tax payer code... etc.

If you want to print only the telephone number, just refer to page 21 of this manual.

The following procedure shows you how to set or edit your numbers including spaces and hyphens.



1st line: → 3 [SUB TOTAL] → 0 1 3 2 [SUB TOTAL] →

2nd line: → 3 [SUB TOTAL] → 0 2 3 2 [SUB TOTAL] →

3rd line: → 3 [SUB TOTAL] → 0 3 3 2 [SUB TOTAL] →

4th line: → 3 [SUB TOTAL] → 0 4 3 2 [SUB TOTAL] →

Enter the number within 14 digits, including spaces and hyphens.

- numerics: 0, 1 ~ 9, 00
- hyphen: -
- space: [POST RECEIPT]

→ CA / AMT = / TEND → [SUB TOTAL]

Example: To print

1 2 3 4 - 5 6 7 8

→ Enter as 1 2 3 4 - 5 6 7 8

1 2 - 0 6 - 9 6

To print

1 2 3
4 5 6 - 7 8 9

→ Enter as 1 2 3 [POST RECEIPT] 4 5 6 - 7 8 [POST RECEIPT] 9

1 2 - 0 6 - 9 6

To print

1 2 3 4 5 6 7 8 9
0 1 2 3 4

→ Enter as 1 2 3 4 5 6 7 8 9 0 1 2 3 4

Note: Entries exceed 9 digits are printed in 2 lines.

High digit limitation for departments

Locking out and releasing high digit limitation

OPERATION

RECEIPT

Item	Unit Price	\$10.50
	Quantity	1
	Dept.	3
	Taxable	(1) _{preset}
	Max.digit	(3) _{preset}
Payment	Cash	\$20.00

1 0 5 0 x 3

ERROR ALARM
(Exceeding max. digits)

C
C/IAC

OPEN/
CLK #

Cancels limitations
for next entry

1 0 5 0 x 3

SUB
TOTAL

2 0 00 CA / AMT = / TEND

12-06-96	
13-50	
1234 0035	
03	• 10.50 I
	• 10.50 I TA
	• 0.42 I TX
	• 10.92 TL
	• 20.00 CA AT
	• 9.08 CG

Single-Item-Sales for departments and PLUs

About the single-item-sales items

You can issue a receipt by simply touching the single-item-sales department or PLU. The following examples show how you register single-item-sale departments. Registration of single-item-sale PLUs is identical.

Example 1

Item	Unit Price	\$2.00
	Quantity	1
	Dept.	4
	Taxable	2
	Sales Status	Single-Item

OPERATION

2 00 ÷ 4

RECEIPT

```

12-06-96
  1 14-00
1234 0036

04      • 2•00 II
          • 2•00 II TA
          • 0•10 II TX

          • 2•10 CA
    
```

Example 2

Item	Unit Price	(\$3.00) _{preset}
	Quantity	3
	Dept.	4
	Taxable	2
	Sales Status	Single-Item

OPERATION

3 X/DATE TIME
÷ 4

RECEIPT

```

12-06-96
  1 14-10
1234 0037

          3 X
          • 3•00 @
04      • 9•00 II
          • 9•00 II TA
          • 0•45 II TX

          • 9•45 CA
    
```

Example 3

Item 1	Unit Price	\$2.00
	Quantity	1
	Dept.	3
	Taxable	2
	Sales Status	Normal
Item 2	Unit Price	\$5.00
	Quantity	1
	Dept.	4
	Taxable	2
	Sales Status	Single-Item
Tender	Cash	\$7.35

OPERATION

2 00 × 3
5 00 ÷ 4

Single-Item status is not effective during transaction.

CA/AMT
= /TEND

It is necessary to press the finalize key.

RECEIPT

```

12-06-96
  1 14-20
1234 0038

03      • 2•00 II
04      • 5•00 II
          • 7•00 II TA
          • 0•35 II TX


          • 7•35 CA
    
```

Note: The single-item-sales department or PLU should be registered at the top of the transaction, otherwise the transaction is not finalized. It is necessary to press **CA/AMT = /TEND**, **CH** or **CHK** key.

Registering Sub-departments

Registering Sub-departments

The following examples show how you can use Sub-departments in various types of registrations. Registering by PLU, see the "Basic Operations and setups" on page 36.



Mode Switch

Sub-department Single-Item-Sale

OPERATION

Item	Unit Price	\$6.00
	Quantity	1
	Sub-Dept.	15
	Taxable	(1) _{preset}
Payment	Cash	\$10.00

1 5
 PLU (Sub-department) code
6 00
 Unit price

1 0 00

RECEIPT

```

12-06-96
 1 14-30
1234 0039

015  .6.00 I
      .6.00 I TA
      .0.24 I TX

      .6.24 TL
      .10.00 CA AT
      .3.76 CG
    
```

Sub-department Repeat

OPERATION

Item 1	Unit Price	(\$3.00) _{preset}
	Quantity	3
	Sub-Dept.	15
	Taxable	(1) _{preset}
Item 2	Unit Price	\$2.00
	Quantity	2
	Sub-Dept.	15
	Taxable	(1) _{preset}
Payment	Cash	\$20.00

1 5

 Hit without a unit price recalls preset price.

1 5
2 00

2 0 00

RECEIPT

```

12-06-96
 1 14-40
1234 0040

015  .3.00 I
015  .3.00 I
015  .3.00 I
015  .2.00 I
015  .2.00 I
      .13.00 I TA
      .0.52 I TX

      .13.52 TL
      .20.00 CA AT
      .6.48 CG
    
```

Convenient Operations and Setups

Sub-department Multiplication

	Unit Price	\$6.00
Item	Quantity	1.25
	Sub-Dept.	15
	Taxable	(1) _{preset}
Payment	Cash	\$10.00

OPERATION

1 **·** **2** **5** FOR DATE TIME
 Quantity
 (4-digit integer/2-digit decimal)
1 **5** PLU/ S.DEPT
6 **00** PRICE
 SUB TOTAL
1 **0** **00** CA/AMT = /TEND

RECEIPT

```

12-06-96
  1 14-50
1234 0041

    1.25 X
    .6.00 @
015 .7.50 I
     .7.50 I TA
     .0.30 I TX

     .7.80 TL
     .10.00 CA AT
     .2.20 CG
  
```

Sub-department Split Sales of Packaged Item

	Unit Price	12 for \$30.00
Item	Quantity	7
	Sub-Dept.	37
	Taxable	(1) _{preset}
Payment	Cash	\$20.00

OPERATION

7 FOR DATE TIME
 Quantity being purchased
 (4-digit integer/2-digit decimal)
1 **2** FOR DATE TIME
 Package quantity
 (4-digit integer/2-digit decimal)
3 **7** PLU/ S.DEPT
3 **0** **00** PRICE
 SUB TOTAL
2 **0** **00** CA/AMT = /TEND

RECEIPT

```

12-06-96
  1 15-00
1234 0042

      7 X
      12
037 .30.00 @
     .17.50 I
     .17.50 I TA
     .0.70 I TX

     .18.20 TL
     .20.00 CA AT
     .1.80 CG
  
```

To program the tax calculation status and maximum entering digits for each department.

Tax calculation status

This digit defines which tax table should be used for automatic tax calculation. See page 15 for information on setting up the tax tables.

U.S.A.

- Tax Table 1 ⇨ **1**
- Tax Table 2 ⇨ **2**
- Tax Table 1 and 2 ⇨ **3**
- No tax calculation ⇨ **0**

Canada

- Tax Table 1 ⇨ **1**
- Tax Table 1 and 2 ⇨ **2**
- Tax Table 1 and 3 ⇨ **3**
- No tax calculation ⇨ **0**

Maximum entering digits

This specification defines how many digits can be used for manual input of a unit price on the keyboard.



- No limit ⇨ **0**
- 1 digit ⇨ **1**
- 2 digits ⇨ **2**
- ⋮
- 5 digits ⇨ **5**
- 6 digits ⇨ **6**
- Manual input not allowed ⇨ **9**

Selecting **9** means that you can perform department registration using their preset unit price only.

Single-Item status/Negative department status

This digit defines single-item status and negative department.

- Normal dept. ⇨ **0**
- Single item dept. ⇨ **1**
- Negative dept. ⇨ **2**
- Single item/
Negative dept. ⇨ **3**



Convenient Operations and Setups

To program PLU links to departments, tax calculation status and PLU/Sub-department selections

Single-Item status/Negative PLU status/PLU, Sub-dept. selection

This digit defines single-item status and negative department.

- Normal PLU ⇒ **0**
- Single item PLU ⇒ **1**
- Negative PLU ⇒ **2**
- Single item/
Negative PLU ⇒ **3**
- Normal Sub-dept. ⇒ **4**
- Single item Sub-dept. ⇒ **5**
- Negative Sub-dept. ⇒ **6**
- Single item/
Negative Sub-dept. ⇒ **7**

Note:

- PLU: Register only its preset price
- Sub-department: Register its preset price and manually entered price.

Tax calculation status

This digit defines which tax table should be used for automatic tax calculation. See page 15 for information on setting up the tax tables.

- U.S.
- Tax Table 1 ⇒ **1**
 - Tax Table 2 ⇒ **2**
 - Tax Table 1 and 2 ⇒ **3**
 - No tax calculation ⇒ **0**
- Canada
- Tax Table 1 ⇒ **1**
 - Tax Table 1 and 2 ⇒ **2**
 - Tax Table 1 and 3 ⇒ **3**
 - No tax calculation ⇒ **0**



Linked department

This specification links the PLU to a department

- U.S.
- Department 1 ⇒ **0 1**
 - ⋮
 - Department 40 ⇒ **4 0**
 - No link ⇒ **0 0**
- Canada
- Department 1 ⇒ **0 1**
 - ⋮
 - Department 10 ⇒ **1 0**
 - No link ⇒ **0 0**


PLU No.

- 1** to **4 0 0** (U.S.)
- 1** to **3 0 0** (Canada)



Registering discounts and premiums

The following example shows how you can use the [%] key as premium in various types of registration. Note: Before registering premium, you should define the [%] key as premium key. See the next page.



Discount for Items and subtotals

Refer to "Preparing and using discounts" in "Basic Operations and Setups" on page 40.

Premium for Items and subtotals

OPERATION

RECEIPT

Item 1	Unit Price	(\$10.00) _{preset}
	Quantity	1
	Dept.	4
	Taxable	(2) _{preset}
Premium	Rate	7%
Item 2	Unit Price	(\$5.00) _{preset}
	Quantity	1
	PLU	32
	Taxable	(2) _{preset}
Subtotal	Rate	(5%) _{preset}
premium	Taxable	(1 and 2) _{preset}
Payment	Cash	\$20.00

Applies the input value as a premium rate (7%).

For this operation, hit this key instead of .

Applies the preset premium rate (5%) to the subtotal.

12-06-96	
1 15-10	
1234 0043	
04	• 10 • 00 II
	7 %
	• 0 • 70 II
032	• 5 • 00 II
	• 15 • 70 ST
	5 %
	• 0 • 79 III
	• 16 • 49 II TA
	• 0 • 82 II TX
	• 17 • 31 TL
	• 20 • 00 CA AT
	• 2 • 69 CG

- You can manually input rates up to 4 digits long (0.01% to 99.99%).

Taxable status of the [%] key

- Whenever you perform a discount/premium operation on the last item registered, the tax calculation for discount/premium amount is performed in accordance with the tax status programmed for that item.
- Whenever you perform a discount/premium operation on a subtotal amount, the tax calculation for the subtotal amount is performed in accordance with the tax status programmed for the [%] key.

Convenient Operations and Setups

Programming discounts and premiums

You can use the [%] key to register either discounts (percentage decreases) or premium (percentage increases). The following procedures let you select the operation you want for [%] key. They also let you program a preset rate, the tax calculation method and the tax rounding method.

To program discount or premium rate.

Refer to "Preparing and using discounts" in "Basic Operations and Setups" on page 40.

To program tax calculation status, tax rounding method and the key attribution.

Tax calculation status

This specification defines where the result of the percent calculation on a subtotal should be reflected (added to or subtracted from) for tax purposes.

Note that this specification is for calculations with subtotal only, and is not applied for calculations involving individual items.

U.S.

- Tax Table 1 ⇨ 1
- Tax Table 2 ⇨ 2
- Tax Table 1 and 2 ⇨ 3
- No tax calculation ⇨ 0

Canada

- Tax Table 1 ⇨ 1
- Tax Table 1 and 2 ⇨ 2
- Tax Table 1 and 3 ⇨ 3
- All taxable ⇨ 4
- No tax calculation ⇨ 0


Tax rounding method

This specification defines the method use to round the result of a percentage calculation.

- Round off ⇨ 0
- Cut off ⇨ 1
- Round up ⇨ 2

Key attribution

- Use as discount key (%-) ⇨ 0
- Use as premium key (%+) ⇨ 1




Registering manually entered tax amounts

You can program the cash register to change the function of the [%] key to that of a [M-TAX] (Manual Tax) key. The [M-TAX] key is used to register manually entered tax amounts.

Important!

If you program the cash register to perform registrations with manually entered tax amounts, the [M-TAX] key replaces the [%] key, so discount/premium registration to be impossible.

Registering manual tax



Example

OPERATION

RECEIPT

Item 1	Unit Price	\$10.00
	Quantity	1
	Dept.	1
	Taxable	No
	M-TAX	Normal
Item 2	Unit Price	\$20.00
	Quantity	1
	Dept.	2
	Taxable	2
Tender	Cash	\$32.00

1 0 00 + 1
5 0 M-TAX
 [%] key is assigned to [M-TAX] key.
2 0 00 _ 2
3 2 00 CA/AMT = /TEND


```

12-06-96
 1 15-20
1234 0044

01 • 10•00
    • 0•50 TX
02 • 20•00 II
    • 20•00 II TA
    • 1•00 II TX

• 31•50 TL
• 32•00 CA AT
• 0•50 CG
    
```


Programming for manually input tax registration



3 [SUB TOTAL] → **0 0 4 0** Fixed value → [%] → [SUB TOTAL]

Other programmable options

Programming amount tender compulsory and prohibit amount tender



Programming credit balance and tax status to subtraction key


Tax calculation status

This specification defines where the result of the subtraction should be reflected (subtracted from) for tax purposes.

U.S.		Canada	
Tax Table 1	⇒ 1	Tax Table 1	⇒ 1
Tax Table 2	⇒ 2	Tax Table 1 and 2	⇒ 2
Tax Table 1 and 2	⇒ 3	Tax Table 1 and 3	⇒ 3
No tax calculation	⇒ 0	All taxable	⇒ 4
		No tax calculation	⇒ 0


Credit balance

- Prohibit credit balance ⇒ 0
- Allow credit balance ⇒ 1



Calculator functions

While registering at the REG mode, you can switch to CAL mode and then return to REG mode to resume the registration.



Example 1 (Calculation examples)

	OPERATION	DISPLAY
Clear		
5+3-2=		
(23-56)x78=		
(4x3-6)/3.5+8=		
12 % on 1500		

Example 2 (Memory recall)

	OPERATION	DISPLAY/RECEIPT																								
<table border="1"> <tr> <td rowspan="4">Item 1</td> <td>Unit Price</td> <td>\$10.00</td> </tr> <tr> <td>Quantity</td> <td>1</td> </tr> <tr> <td>Dept.</td> <td>1</td> </tr> <tr> <td>Taxable</td> <td>(1)_{preset}</td> </tr> <tr> <td rowspan="4">Item 2</td> <td>Unit Price</td> <td>\$20.00</td> </tr> <tr> <td>Quantity</td> <td>1</td> </tr> <tr> <td>Dept.</td> <td>2</td> </tr> <tr> <td>Taxable</td> <td>(1)_{preset}</td> </tr> <tr> <td colspan="2">Payment by 3 persons</td> <td></td> </tr> <tr> <td>Cash</td> <td>\$10.40_{each}</td> <td></td> </tr> </table>	Item 1	Unit Price	\$10.00	Quantity	1	Dept.	1	Taxable	(1) _{preset}	Item 2	Unit Price	\$20.00	Quantity	1	Dept.	2	Taxable	(1) _{preset}	Payment by 3 persons			Cash	\$10.40 _{each}		 <p>Memory recall: Recalls subtotal amount</p> <p>Divide the subtotal by 3 persons.</p> <p>Memory recall: Recalls the result amount</p> 	
Item 1		Unit Price	\$10.00																							
		Quantity	1																							
		Dept.	1																							
	Taxable	(1) _{preset}																								
Item 2	Unit Price	\$20.00																								
	Quantity	1																								
	Dept.	2																								
	Taxable	(1) _{preset}																								
Payment by 3 persons																										
Cash	\$10.40 _{each}																									

Convenient Operations and Setups

Convenient Operations and Setups

Note:

- Pressing PLU/S.DEPT key in the CAL mode recalls
 - Current subtotal (During registration)
 - The last amount (Registration has been completed)
- Pressing PLU/S.DEPT key in the REG mode recalls
The current result by pressing CA/AMT =/TEND key at the CAL mode.


Programming calculator mode control

The following procedure lets you program a number of functions in CAL mode.

- Open/Not open the cash drawer when the "Equal" key (CA/AMT =/TEND key on the keyboard) is pressed.
- Open/Not open the cash drawer when the "Drawer open" key (\# / NS or NS key on the keyboard) is pressed.
- Print/Skip the "Equal" key total/count on the daily READ/RESET report.

default

Open/Not open drawer when the CA/AMT =/TEND (equal) key is pressed in CAL mode.	a	Not open = 0 Open = 1	<div style="border: 1px solid black; width: 20px; height: 20px; display: inline-block;"></div> (a+b+c)
Open/Not open drawer when the \# / NS / NS (drawer open) key is pressed in CAL mode.	b	Not open = 0 Open = 2	
Print/Skip the CA/AMT =/TEND (equal) key total and count on the daily report.	c	Print = 0 Skip = 4	



Printing READ/RESET reports

- **READ report**
You can print READ reports at any time during the business day without affecting the data stored in the cash register's memory.
- **RESET report**
You should print RESET reports at the end of the business day.

Important!

- **The RESET operation issues a report and also clears all sales data from the cash register's memory.**
- **Be sure to perform the RESET operations at the end of each business day. Otherwise, you will not be able to distinguish between the sales data for different dates.**

To print the individual department READ report


This report shows sales for specific departments.

OPERATION	REPORT																																							
<div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> <p style="text-align: center;">Mode Switch</p> </div> <p style="text-align: center;">↓</p> <p style="text-align: center;">Specifying a department</p> <p style="text-align: center;"> <input type="button" value="+ 1"/> ... <input type="button" value="10"/> (Canada) <input type="button" value="+ 1"/> ... <input type="button" value="40"/> DEPT SHIFT <input type="button" value="+ 1"/> ... <input type="button" value="40"/> DEPT SHIFT (U.S.) </p> <p style="text-align: center;">If you want to read any other department, continue specifying department keys ...</p> <p style="text-align: center;">↓</p> <p style="text-align: center;"><input type="button" value="SUB TOTAL"/></p> <p style="text-align: center;">After you finish to select departments, press <input type="button" value="SUB TOTAL"/> to terminate.</p>	<table border="0" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 60%; text-align: right;">12-06-96</td> <td style="width: 5%;"></td> <td style="width: 35%;">Date</td> </tr> <tr> <td style="text-align: right;">1 15-40</td> <td></td> <td>Clerk No./Time</td> </tr> <tr> <td style="text-align: right;">1234 0046</td> <td></td> <td>Machine No./Consecutive No.</td> </tr> <tr> <td style="text-align: center;">X</td> <td></td> <td>READ symbol</td> </tr> <tr> <td style="text-align: right;">01 15</td> <td></td> <td>Department No./No. of items</td> </tr> <tr> <td style="text-align: right;">. 339.50</td> <td></td> <td>Department amount</td> </tr> <tr> <td style="text-align: right;">02 19</td> <td></td> <td></td> </tr> <tr> <td style="text-align: right;">. 62.70</td> <td></td> <td></td> </tr> <tr> <td style="text-align: right;">03 31</td> <td></td> <td></td> </tr> <tr> <td style="text-align: right;">. 139.10</td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">.....</td> <td></td> <td></td> </tr> <tr> <td style="text-align: right;">253</td> <td></td> <td>Total No. of items</td> </tr> <tr> <td style="text-align: right;">. 1146.90</td> <td style="text-align: right;">IL</td> <td>Total amount</td> </tr> </table>	12-06-96		Date	1 15-40		Clerk No./Time	1234 0046		Machine No./Consecutive No.	X		READ symbol	01 15		Department No./No. of items	. 339.50		Department amount	02 19			. 62.70			03 31			. 139.10					253		Total No. of items	. 1146.90	IL	Total amount
12-06-96		Date																																						
1 15-40		Clerk No./Time																																						
1234 0046		Machine No./Consecutive No.																																						
X		READ symbol																																						
01 15		Department No./No. of items																																						
. 339.50		Department amount																																						
02 19																																								
. 62.70																																								
03 31																																								
. 139.10																																								
.....																																								
253		Total No. of items																																						
. 1146.90	IL	Total amount																																						

Convenient Operations and Setups


To print the individual PLU/sub-department READ report

This report shows sales for specific PLUs/sub-departments.

OPERATION	REPORT																								
 <p>Mode Switch</p> <p>Specifying a PLU/Sub-department by its code</p> <p>(1 ~ 4 00)^{*1}</p> <p>PLU/SDEPT^{*2}</p> <p>If you want to read any other PLU/Sub-department, continue specifying codes...</p> <p>SUB TOTAL</p> <p>After you finish to select PLU/Sub-department, press SUB TOTAL to terminate.</p>	<table border="1"> <tr><td>12-06-96</td><td>Date</td></tr> <tr><td>1 15-50</td><td>Clerk No./Time</td></tr> <tr><td>1234 0047</td><td>Machine No./Consecutive No.</td></tr> <tr><td>X</td><td>READ symbol</td></tr> <tr><td>003 21</td><td>PLU/Sub-department No./No. of items</td></tr> <tr><td>• 27 • 30</td><td></td></tr> <tr><td>050 12</td><td>PLU/Sub-department amount</td></tr> <tr><td>• 36 • 00</td><td></td></tr> <tr><td>021 13</td><td></td></tr> <tr><td>• 65 • 36</td><td></td></tr> <tr><td>46</td><td>Total No. of items</td></tr> <tr><td>• 128 • 30 TL</td><td>Total amount</td></tr> </table>	12-06-96	Date	1 15-50	Clerk No./Time	1234 0047	Machine No./Consecutive No.	X	READ symbol	003 21	PLU/Sub-department No./No. of items	• 27 • 30		050 12	PLU/Sub-department amount	• 36 • 00		021 13		• 65 • 36		46	Total No. of items	• 128 • 30 TL	Total amount
12-06-96	Date																								
1 15-50	Clerk No./Time																								
1234 0047	Machine No./Consecutive No.																								
X	READ symbol																								
003 21	PLU/Sub-department No./No. of items																								
• 27 • 30																									
050 12	PLU/Sub-department amount																								
• 36 • 00																									
021 13																									
• 65 • 36																									
46	Total No. of items																								
• 128 • 30 TL	Total amount																								
	<p>^{*1} 1 ~ 3 00 for Canada</p> <p>^{*2} Press PLU/SDEPT directly to specify the next PLU/Sub-department.</p>																								

To print the financial READ report

This report shows gross sales, net sales, cash in drawer and check in drawer.

OPERATION	REPORT																										
 <p>Mode Switch</p> <p>Money declaration^{*2}</p> <p>(Cash in drawer amount #/NS, NS)</p> <p>X/FOR DATE TIME</p>	<table border="1"> <tr><td>12-06-96</td><td>Date</td></tr> <tr><td>1 16-00</td><td>Clerk No./Time</td></tr> <tr><td>1234 0048</td><td>Machine No./Consecutive No.</td></tr> <tr><td>X</td><td>READ symbol</td></tr> <tr><td>253</td><td>Gross No. of items</td></tr> <tr><td>• 1146 • 90 TL</td><td>Gross amount</td></tr> <tr><td>100 No</td><td>Net No. of customers</td></tr> <tr><td>• 1217 • 63 NT</td><td>Net amount</td></tr> <tr><td>• 908 • 06 CA #</td><td>Cash in drawer (b)</td></tr> <tr><td>• 908 • 06 #</td><td>Declared amount (a)</td></tr> <tr><td>• 0 • 00</td><td>Difference (a) with (b)</td></tr> <tr><td>• 125 • 97 CH #</td><td>Charge in drawer</td></tr> <tr><td>• 183 • 60 CK</td><td>Check in drawer</td></tr> </table>	12-06-96	Date	1 16-00	Clerk No./Time	1234 0048	Machine No./Consecutive No.	X	READ symbol	253	Gross No. of items	• 1146 • 90 TL	Gross amount	100 No	Net No. of customers	• 1217 • 63 NT	Net amount	• 908 • 06 CA #	Cash in drawer (b)	• 908 • 06 #	Declared amount (a)	• 0 • 00	Difference (a) with (b)	• 125 • 97 CH #	Charge in drawer	• 183 • 60 CK	Check in drawer
12-06-96	Date																										
1 16-00	Clerk No./Time																										
1234 0048	Machine No./Consecutive No.																										
X	READ symbol																										
253	Gross No. of items																										
• 1146 • 90 TL	Gross amount																										
100 No	Net No. of customers																										
• 1217 • 63 NT	Net amount																										
• 908 • 06 CA #	Cash in drawer (b)																										
• 908 • 06 #	Declared amount (a)																										
• 0 • 00	Difference (a) with (b)																										
• 125 • 97 CH #	Charge in drawer																										
• 183 • 60 CK	Check in drawer																										

^{*2} Money declaration:

Count how much cash is in the drawer and input this amount (up to 8 digits).

The cash register will automatically compare the input with the cash in drawer in the memory and print the difference between these two amounts.



Note that if money declaration is required by programming (page 57), you cannot skip this procedure.

To print the daily sales READ/RESET report

This report shows sales except for PLUs.

OPERATION

REPORT



MONEY DECLARATION *1
(Cash in drawer amount #/NS, NS)

CA/AMT
= /TEND

12-06-96	Date
1 16-10	Clerk No./Time
1234 0049	Machine No./Consecutive No.
000 X	Report code/READ symbol
01 15	Department No./No. of items*2
• 339 • 50	Department amount*2
• 62 • 70	
00 16	Non-link department count
• 94 • 90	Non-link department amount
253	Gross No. of items
• 1146 • 90 TL	Gross sales
10 No	Subtraction count
• 4 • 62 -	Subtraction amount
8 No	Premium/Discount count
• 3 • 00 % -	Premium/Discount amount
• 732 • 56 I TA	Taxable amount 1*3
• 56 • 80 I TX	Tax amount 1*3
• 409 • 72 II TA	Taxable amount 2*3
• 21 • 55 II TX	Tax amount 2*3
• 272 • 50 III TA	Taxable amount 3 (Canada only)*3
• 21 • 55 III TX	Tax amount 3 (Canada only)*3
100 No	No. of customers

• 1217 • 63 NT	Net amount
1 10 No	Clerk 1 count
• 14 • 62	Clerk 1 sales amount
25 No	
• 51	
81 No	Cash sales count
• 836 • 86 CA	Cash sales amount
10 No	Charge sales count
• 197 • 17 CH	Charge sales amount
9 No	Check sales count
• 183 • 60 CK	Check sales amount
2 No	Received on Account count
• 78 • 00 RC	Received on Account amount
1 No	Paid out count
• 6 • 80 PD	Paid out amount
10 No	Error correction count
• 12 • 76 VD	
2 No	Cancellation count
• 108 • 52 * VD	Refund key count*4
7 No	
• 27 • 79 RF	Refund mode operation count*4
2 No	Refund mode operation amount*4
• 3 • 74 * RF	Refund mode operation amount*4
5 #	No sale count
3 CA No	CAL mode operation count*4
• 908 • 06 CA #	Cash in drawer amount
• 125 • 97 CH #	Charge in drawer amount
• 183 • 60 CK	Check in drawer amount
• 000000	Non-resettable grand-sales total (RESET report only)
001217 • 63	

*1 Money declaration:

Count how much cash is in the drawer and input this amount (up to 8 digits).

The cash register will automatically compare the input with the cash in drawer in the memory and print the difference between these two amounts.

Note that if money declaration is required by programming (page 57), you cannot skip this procedure.

*2 Zero totaled departments (the amount and item numbers are both zero) are not printed.

*3 Taxable amount and tax amount are printed only the corresponding tax table is programmed.

*4 These items can be skipped by programming.

5 The "" symbol is printed on the RESET report, memory overflow occurred in the totalizer.

Convenient Operations and Setups

To print the PLU/sub-department READ/RESET report

This report shows sales for PLUs/sub-departments.

OPERATION	REPORT																																																							
<p>Mode Switch</p> <p>1 CA/AMT = /TEND</p>	<table border="0"> <tr> <td>12-06-96</td> <td>—</td> <td>Date</td> </tr> <tr> <td>1 16-20</td> <td>—</td> <td>Clerk No./Time</td> </tr> <tr> <td>1234 0050</td> <td>—</td> <td>Machine No./Consecutive No.</td> </tr> <tr> <td>001 X</td> <td>—</td> <td>READ symbol (RESET symbol and counter are printed on RESET report)</td> </tr> <tr> <td>001 21</td> <td>—</td> <td rowspan="2">PLU/Sub-department No./ No. of items</td> </tr> <tr> <td>•27•30</td> <td>—</td> </tr> <tr> <td>002 12</td> <td>—</td> <td rowspan="2">PLU/Sub-department amount</td> </tr> <tr> <td>•36•00</td> <td>—</td> </tr> <tr> <td>003 13</td> <td>—</td> <td rowspan="2">PLU/Sub-department amount</td> </tr> <tr> <td>•65•36</td> <td>—</td> </tr> <tr> <td>004 68</td> <td>—</td> <td rowspan="2">PLU/Sub-department amount</td> </tr> <tr> <td>•47•94</td> <td>—</td> </tr> <tr> <td>005 13</td> <td>—</td> <td rowspan="2">PLU/Sub-department amount</td> </tr> <tr> <td>•76•00</td> <td>—</td> </tr> <tr> <td>102 12</td> <td>—</td> <td rowspan="2">PLU/Sub-department amount</td> </tr> <tr> <td>•24•00</td> <td>—</td> </tr> <tr> <td>150 13</td> <td>—</td> <td rowspan="2">PLU/Sub-department amount</td> </tr> <tr> <td>•33•34</td> <td>—</td> </tr> <tr> <td>.....</td> <td>—</td> <td rowspan="2">Total No. of items</td> </tr> <tr> <td>246</td> <td>—</td> </tr> <tr> <td>•3128•30 TL</td> <td>—</td> <td>Total amount</td> </tr> </table>	12-06-96	—	Date	1 16-20	—	Clerk No./Time	1234 0050	—	Machine No./Consecutive No.	001 X	—	READ symbol (RESET symbol and counter are printed on RESET report)	001 21	—	PLU/Sub-department No./ No. of items	•27•30	—	002 12	—	PLU/Sub-department amount	•36•00	—	003 13	—	PLU/Sub-department amount	•65•36	—	004 68	—	PLU/Sub-department amount	•47•94	—	005 13	—	PLU/Sub-department amount	•76•00	—	102 12	—	PLU/Sub-department amount	•24•00	—	150 13	—	PLU/Sub-department amount	•33•34	—	—	Total No. of items	246	—	•3128•30 TL	—	Total amount
12-06-96		—	Date																																																					
1 16-20	—	Clerk No./Time																																																						
1234 0050	—	Machine No./Consecutive No.																																																						
001 X	—	READ symbol (RESET symbol and counter are printed on RESET report)																																																						
001 21	—	PLU/Sub-department No./ No. of items																																																						
•27•30	—																																																							
002 12	—	PLU/Sub-department amount																																																						
•36•00	—																																																							
003 13	—	PLU/Sub-department amount																																																						
•65•36	—																																																							
004 68	—	PLU/Sub-department amount																																																						
•47•94	—																																																							
005 13	—	PLU/Sub-department amount																																																						
•76•00	—																																																							
102 12	—	PLU/Sub-department amount																																																						
•24•00	—																																																							
150 13	—	PLU/Sub-department amount																																																						
•33•34	—																																																							
.....	—	Total No. of items																																																						
246	—																																																							
•3128•30 TL	—	Total amount																																																						
<p>Mode Switch</p> <p>1 CA/AMT = /TEND</p>																																																								

To print the hourly sales READ/RESET report

This report shows hourly breakdowns of sales.



OPERATION	REPORT																																													
<p>Mode Switch</p> <p>2 CA/AMT = /TEND</p>	<table border="0"> <tr> <td>12-06-96</td> <td>—</td> <td>Date</td> </tr> <tr> <td>1 16-30</td> <td>—</td> <td>Clerk No./Time</td> </tr> <tr> <td>1234 0051</td> <td>—</td> <td>Machine No./Consecutive No.</td> </tr> <tr> <td>002 X</td> <td>—</td> <td>READ symbol (RESET symbol and counter are printed on RESET report)</td> </tr> <tr> <td>10-11</td> <td>—</td> <td rowspan="2">Time zone</td> </tr> <tr> <td>17 No</td> <td>—</td> </tr> <tr> <td>•171•83</td> <td>—</td> <td rowspan="2">No. of customers</td> </tr> <tr> <td>11-12</td> <td>—</td> </tr> <tr> <td>21 No</td> <td>—</td> <td rowspan="2">Amount</td> </tr> <tr> <td>•96•20</td> <td>—</td> </tr> <tr> <td>•331•00</td> <td>—</td> <td rowspan="2">Amount</td> </tr> <tr> <td>20-21</td> <td>—</td> </tr> <tr> <td>11 No</td> <td>—</td> <td rowspan="2">Amount</td> </tr> <tr> <td>•96•20</td> <td>—</td> </tr> <tr> <td>.....</td> <td>—</td> <td rowspan="2">Total No. of items</td> </tr> <tr> <td>246</td> <td>—</td> </tr> <tr> <td>•3128•30 TL</td> <td>—</td> <td>Total amount</td> </tr> </table>	12-06-96	—	Date	1 16-30	—	Clerk No./Time	1234 0051	—	Machine No./Consecutive No.	002 X	—	READ symbol (RESET symbol and counter are printed on RESET report)	10-11	—	Time zone	17 No	—	•171•83	—	No. of customers	11-12	—	21 No	—	Amount	•96•20	—	•331•00	—	Amount	20-21	—	11 No	—	Amount	•96•20	—	—	Total No. of items	246	—	•3128•30 TL	—	Total amount
12-06-96		—	Date																																											
1 16-30	—	Clerk No./Time																																												
1234 0051	—	Machine No./Consecutive No.																																												
002 X	—	READ symbol (RESET symbol and counter are printed on RESET report)																																												
10-11	—	Time zone																																												
17 No	—																																													
•171•83	—	No. of customers																																												
11-12	—																																													
21 No	—	Amount																																												
•96•20	—																																													
•331•00	—	Amount																																												
20-21	—																																													
11 No	—	Amount																																												
•96•20	—																																													
.....	—	Total No. of items																																												
246	—																																													
•3128•30 TL	—	Total amount																																												
<p>Mode Switch</p> <p>2 CA/AMT = /TEND</p>																																														

To print the periodic sales READ/RESET report

This report shows sales breakdowns of sales by any period you want.

OPERATION

REPORT



Mode Switch

Mode Switch

1 0 0

2 0 0

CA/AMT
= /TEND

CA/AMT
= /TEND

12-31-96	Date
1 17-55	Clerk No./Time
1234 0247	Machine No./Consecutive No.
200 0001Z	Report code/RESET symbol
01 15	Department No./No. of items*1
• 339.50	Department amount*1
02 19	
• 94.90	Non-link department amount
00 16	Non-link department count
• 94.90	Non-link department amount
253	Gross No. of items
• 1146.90 TL	Gross sales
10 No	Subtraction count
• 4.62 -	Subtraction amount
8 No	Premium/Discount count
• 3.00 % -	Premium/Discount amount
• 732.56 I TA	Taxable amount 1*2
• 56.80 I TX	Tax amount 1*2
• 409.72 II TA	Taxable amount 2*2
• 21.55 II TX	Tax amount 2*2
• 272.50 III TA	Taxable amount 3 (Canada only)*2
• 21.55 III TX	Tax amount 3 (Canada only)*2
100 No	No. of customers
• 1217.63 NI	Net amount

1 10 No	Clerk 1 count
• 14.62	Clerk 1 sales amount
2 25 No	
• 21.38	
81 No	Cash sales count
• 836.86 CA	Cash sales amount
10 No	Charge sales count
• 197.17 CH	Charge sales amount
9 No	Check sales count
• 183.60 CK	Check sales amount
2 No	Received on Account count
• 78.00 RC	Received on Account amount
1 No	Paid out count
• 6.80 PD	Paid out amount
10 No	Error correction count
• 12.76 VD	
2 No	Cancellation count
• 108.52 * VD	
7 No	Refund key count*3
• 27.79 RF	
2 No	Refund mode operation count*3
• 3.74 * RF	Refund mode operation amount*3
5 #	No sale count
3 CA No	CAL mode operation count*3
• 908.06 CA #	Cash in drawer amount
• 125.97 CH #	Charge in drawer amount
• 183.60 CK	Check in drawer amount

*1 Zero totalled departments (the amount and item numbers are both zero) are not printed.

*2 Taxable amount and tax amount are printed only the corresponding tax table is programmed.


*3 These items can be skipped by programming.

Printing the cash register's program

To print programming (except PLU)

OPERATION

REPORT



Mode Switch




12-06-96	Date
09-15	Time
1234 0005	Machine No./Consecutive No.
X	READ symbol
01 •1•00 I @	Dept. No./Unit price/Tax status
02 •2•00 II @	Single item status/Listing capacity ^{*1}
03 •3•00 III @	
40•00 I @	
0000 CA	Cash key programming
0000 CH	Charge key programming
0000 CK	Check key programming
I -	Minus key programming
0100 -	Minus key programming
12•34 % -	Discount/Premium rate
III	Discount/Premium key programming
0300 % -	Discount/Premium key programming
0122••0032	Monetary mode/Date printing order
0222••1234	Store/Machine number
0522••0020	Printing controls
0622••0001	Compulsory/Calculation method control
0822••0000	Printing control of X/Z report
1022••0000	Calculation mode control
0125	
10 %	
5002	Tax table 1 ^{*1}
0000	
0225	
0 %	
0000	Tax table 2 ^{*1}
02	
0032	
0325	
10•25 %	
5002	Tax table 3 ^{*1}
0000	
0132	
801-	Tel. number
127-4567	
12-06-96	Date

^{*1} Department or tax table without being programmed are not printed on this report.

To print programming

OPERATION



Mode Switch



REPORT

12-06-96	Date
09-30	Time
1234 0006	Machine No./Consecutive No.
X	READ symbol
001 • 1.00 I @	PLU No./Unit price/Tax status* ¹
0012	Single item status/Link dept.* ¹
002 • 2.00 II @	
0012	
003 • 3.00 III @	
0012	
004 • 4.00 I @	
0012	
12-06-96	
	Date

*¹ PLU without being programmed is not printed on this report.


Troubleshooting

This section describes what to do when you have problems with operation.

When an error occurs...

Errors are indicated by an error tone. When this happens, you can usually find out what the problem is as illustrated below.


ERROR TONE




Does the display show an error code?

No


Yes

Error Code	Meaning	Action
E01	Mode Switch position changed before finalization.	Return the Mode Switch to its original setting and finalize the operation.
E08	Registration without entering a clerk number. This error appears only when the clerk control function is activated.	Enter a clerk number.
E27	Transaction cancel buffer is full.	Finalize the transaction.
E31	Finalization of a transaction attempted without confirming the subtotal.	Press the  key.
E33	Finalize operation attempted without entering amount tendered.	Enter the amount tendered.
E38	READ/RESET operation without declaring cash in drawer. This error appears only when this function is activated.	Perform money declaration.
E94	Printer error.	Turn the power off, and remove jammed paper from the printer.

Press  key and check the appropriate section of this manual for the operation you want to perform.

When the register does not operate at all...

Perform the following check whenever the cash register enter an error condition as soon as you switch it on. The results of this check are required by service personnel, so be sure to perform this check before you contact a CASIO representative for servicing.



In case of power failure...

If the power supply to the cash register is cut by a power failure or any other reason, simply wait for power to be restored. The details of any on-going transaction as well as all sales data in memory are protected by the memory backup batteries.

- Power failure during a registration
The subtotal for items registered up to the power failure is retained in memory. You will be able to continue with the registration when power is restored.
- Power failure during printing a READ/RESET report
The data already printed before the power failure is retained in memory. You will be able to issue a report when power is restored.
- Power failure during printing of a receipt and the journal
Printing will resume after power is restored. A line that was being printed when the power failure occurred is printed in full.
- Other
The power failure symbol is printed and any item that was being printed when the power failure occurred is reprinted in full.

Important!

Once receipt/journal printing or printing of a report starts, it can be stopped only by interruption of power to the cash register.

When the L sign appears on the display

About the low battery indicator...

The following shows the low battery indicator.



If this indicator appears when you switch the cash register on, it can mean one of three things:

- No memory backup batteries are loaded in the cash register.
- The power of the batteries loaded in the unit is below a certain level.
- The batteries loaded in the unit are dead.

To clear this sign, press  key.


Important!

Whenever the low battery indicator appears on the display, load a set of three new batteries as soon as possible. If there is a power failure or you unplug the cash register when this indicator appears, you will lose all of your sales data and settings.

**BE SURE TO KEEP THE POWER CORD OF THE CASH REGISTER
PLUGGED IN WHENEVER YOU REPLACE THE BATTERIES.**

To replace the ink ribbon



1. Remove the printer cover.
2. Remove the inner cover by grasping its top on the left side and lifting up to the right.
3. Unroll about 10 centimeters of ribbon and place the take-up spool on the left shaft.
4. Insert the ribbon into the ribbon feed slot between the printer rollers. Loop the ribbon around the outside guard brackets as in the illustration.
5. Move the ribbon clip to the left. While holding the clip open, place the feed spool on the right shaft and take up any slack in the ribbon.



Important!


Use only the RAP-01 ribbon (purple). Other types of ink ribbons can damage the printer. Never try to extend the life of an ink ribbon by replenishing the ink. Once an ink ribbon is in place, press the  or  key to test for correct operation.

To replace journal paper




1

Set the Mode Switch to the REG position and remove the printer cover.




2

Press the **FEED** to feed about 20 cm of paper.



7

Cut the journal paper as shown in the photograph.



3

Cut the journal paper at the point where nothing is printed.



8

Press the **FEED** to feed the remaining paper from the printer.




4

Remove the journal take-up reel from its holder.



9

Do not pull the paper out of the printer by hand. It can damage the printer.



5

Remove the flat plate from the side of the take-up reel.



10

Remove the old paper roll from the cash register.





6

Slide the printed journal from the take-up reel.

11


Load new paper as described on page 10 of this manual.

To replace receipt paper




1

Set the Mode Switch to the REG position and remove the printer cover.



2

Cut the receipt paper as shown in the photograph.




4

Do not pull the paper out of the printer by hand. It can damage the printer.



3

Press **FEED** to feed the remaining paper from the printer.



5

Remove the old paper roll from the cash register.

6

Load new paper as described on page 9 of this manual.

Options

WT-73 Wetproof Cover

The optional wetproof cover protects the keyboard from moisture damage.

Specifications

INPUT METHOD

Entry: 10-key system; Buffer memory 8 keys (2-key roll over)
 Department: Full key system

DISPLAY (LED)

Amount 8 digits (Zero suppression); Department No.; PLU No.;
 No. of repeats; TOTAL; CHANGE; X mode; Z mode; Receipt On/Off

PRINTER

Printer: Single sheet impact printer (Receipt or journal printing)
 12 digits (Amount 10 digits/Symbol 2 digits)
 Journal: Automatic take up roll winding
 Print speed: 3.2 lines/sec.
 Feed speed: 3.2 lines/sec.
 Paper roll: 58 mm x 80 mm Ø (Max.)
 2-ply paper roll 58 mm x 80 mm Ø (Max.)
 CASIO CP-5880

CALCULATIONS

Entry 8 digits; Registration 7 digits; Total 8 digits

CHRONOLOGICAL DATA

Date print: Automatic date printout on receipt or journal
 Automatic calendar
 Time print: Automatic time printout on receipt or journal
 Time display: 24-hour system

ALARM

Entry confirmation signal; Error alarm

TOTALIZERS

Category	No. of Totalizers	Contents				Periodic Totalizers
		Amount (8 digits)	No. of items (4 digits)	Count (4 digits)	No. of customers (4 digits)	
Department	40 (U.S.) 10 (Canada)	<input type="radio"/>	<input type="radio"/> (4 digits integer/ 2 digits decimal)			<input type="radio"/>
PLU	400 (U.S.) 300 (Canada)	<input type="radio"/>	<input type="radio"/> (4 digits integer/ 2 digits decimal)			
Hourly sales	24	<input type="radio"/>			<input type="radio"/>	
Clerk*	10	<input type="radio"/>			<input type="radio"/>	
Transaction	25	<input type="radio"/> or <input type="radio"/>		<input type="radio"/> or <input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Non resettable grand sales total	1	<input type="radio"/> 14 digits				
Reset counter	4			<input type="radio"/>		<input type="radio"/>
Consecutive No.	1			<input type="radio"/> 4 digits		

* Available only when the clerk control function is active on the cash register.

Memory protection batteries

The effective service life of the memory protection batteries (three new SUM-3 or UM-3 type batteries) is approximately one year from installation into the machine.

Power supply/ Power consumption

As noted on the plate affixed to right side of register.

Operating temperature

32°F-104°F(0°C-40°C)

Humidity

10 - 90%

Dimensions and Weight

10^{19/32}"(H)x13^{11/16}"(W)x15^{9/32}"(D)/14lbs 6oz.
 284mm (H)x400mm (W)x468mm (D)/10.5kg

with small size drawer (U.S.)
 with medium size drawer (Canada)

* Specifications and design are subject to change without notice.

- A**
- Amount tender compulsory 68
 - Arithmetic operation key 27, 69
- B**
- Battery compartment 8, 22
- C**
- Calculator mode 23, 69
 - Cancel (key) 26
 - Cancel (registration) 52
 - Change preparation 30
 - Charge (key) 27
 - Charge (registration) 46
 - Cash/Amount tender key 31, 32
 - Check (key) 27
 - Check (registration) 46
 - Clear (key) 26
 - Clear (operation) 50, 69
 - Clerk key 26
 - Clerk sign on/off 54
 - Correction 50, 51
 - Consecutive number 28, 56, 57
- D**
- Daily sales report 53, 73
 - Date & time display 30
 - Date & time setting 14
 - Department key 26
 - Department registration 31, 32
 - Department report 71
 - Discount 40, 41, 65, 66
 - Display 25
 - Drawer 22, 23, 24
 - Drawer key 22, 23
 - Drawer open key 27
 - Drawer release lever 24
- E**
- Equal key 27
 - Error code 78
 - Error correct key 26
 - Error correct registration 50, 51
- F**
- Feed key 26
 - Financial report 72
- G**
- Grand total 53, 73
- H**
- High digit limitation 59
- I**
- Ink ribbon (location) 22
 - Ink ribbon (replacement) 81
 - Item counter 28
- J**
- Journal 12, 14, 28
 - Journal skip 28, 56
- K**
- Key (Drawer key) 22, 23
 - Key (Mode key) 22, 23
 - Key (Operator key) 23
 - Key (Program key) 23
 - Keyboard 22, 26, 27
- L**
- Low battery indicator 80
 - Load 1-ply paper for journal 12
 - Load 1-ply paper for receipt 11
 - Load 2-ply paper 13
- M**
- Machine number 28, 58
 - Main display 22, 25
 - Memory backup battery 8, 9
 - Memory recall 69
 - Merchandise subtotal 27, 41, 44, 52
 - Minus key (reduction) 42, 43
 - Mode key 23
 - Mode switch 23
 - Money declaration 57, 72, 73
 - Multiplication key 26
 - Multiplication registration 32, 38, 62
- N**
- Negative department 63
 - Negative PLU (Sub-department) 64
 - Non-add key 26
 - Non-add registration 46
 - Non-resettable grand total 53, 73
 - No sale key 26, 27
 - No sale registration 52

- O**
- Open key 26
 - Open key operation 59
 - Operator key 23
- P**
- Paid out key 27
 - Paid out registration 49
 - Paper feed key 26
 - Paper installation 10 ~ 13
 - Percent key 26
 - Percent registration 40, 41, 65, 66
 - Periodic report 75
 - PLU/Sub-department key 26
 - PLU registration 36 ~ 39
 - Pop-up display 22, 25
 - Post receipt 55
 - Post receipt key 26
 - Power failure 80
 - Premium 65, 66
 - Preset price (department) 33, 35
 - Preset price (PLU) 36, 38
 - Preset price (sub-department) 36, 61
 - Printout selection (Receipt/Journal) 14
 - Printer cover 22
 - Price key 26
 - Program read 76, 77
 - Program key 23
- Q**
- R**
- Read report 71 ~ 75
 - Receipt on/off key 22, 27
 - Receipt on/off indicator 25
 - Received on Account key 26
 - Received on Account registration 49
 - Reduction (minus key) 42, 43
 - Refund key 26
 - Refund key registration 47
 - Refund mode 23
 - Refund mode registration 48
 - Register mode 23
 - Repeat counter 25
 - Repeat registration 32, 38, 61
 - Reset report 53, 73 ~ 75
 - Return operation 47, 48
 - Roll paper installation 10 ~ 13
 - Roll paper specification 84
- S**
- Single-item-sale 60
 - Split package pricing 32, 39, 62
 - Store number (machine number) 28, 58
 - Store telephone number 21, 59
 - Sub-department 61, 62, 64
 - Subtotal compulsory 57
 - Subtotal key 27
 - Subtotal printing 56
 - Subtotal registration 32
- T**
- Take-up reel 22
 - Tax table (CANADA tax programming) 20
 - Tax table (U.S. tax programming) 15 ~ 19
 - Tax calculation status (department) 34, 63
 - Tax calculation status (PLU/Sub-dept.) 37, 64
 - Tax calculation status (discount/premium) 40, 66
 - Tax calculation status (reduction) 42, 68
 - Tax shift key 26, 27
 - Tax shift operation 45
 - Time setting 14
- V**
- W**
- X**
- X indicator 25
 - X mode 23
 - X report (READ report) 71 ~ 75
- Y**
- Z**
- Z indicator 25
 - Z mode 23
 - Z report (RESET report) 53, 73 ~ 75

LIMITED WARRANTY: ELECTRONIC CASH REGISTERS

This product, except the battery, is warranted by Casio to the original purchaser to be free from defects in material and workmanship under normal use for a period, from the date of purchase, of one year for a parts and 90 days for labor. For one year, upon proof of purchase, the product will be repaired or replaced (with the same or a similar model) at Casio's option, at a Casio Authorized Service Center without charge of parts. Labor will be provided without charge of 90 days. The terminal resident software and programmable software, if any, included with this product or any programmable software which may be licensed by Casio or one of its authorized dealers, is warranted by Casio to the original licensee for a period of ninety (90) days from the date of license to conform substantially to published specifications and documentation provided it is used with the Casio hardware and software for which it is designed. For a period of ninety (90) days, upon proof of license, Casio will, at its option, replace defective terminal resident software or programmable software, correct significant program errors, or refund the license fee for such software. Significant program errors will be significant deviations from written documentation or specifications. These are your sole remedies for any breach of warranty. In no event will Casio's liability exceed the license fee, if any, for such software. This warranty will not apply if the product has been misused, abused, or altered.

Without limiting the foregoing, battery leakage, bending of the unit, a broken display tube, and any cracks or breaks in the display will be presumed to have resulted from misuse or abuse. To obtain warranty service you must take or ship the product, freight prepaid, with the copy of the sales receipt or other proof of purchase and the date of purchase, to a Casio Authorized service Center. Due to the possibility of damage or loss, it is recommended when shipping the product to a Casio Authorized Service Center that you package the product securely and ship it insured. CASIO HEREBY EXPRESSLY DISCLAIMS ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR OF FITNESS FOR A PARTICULAR PURPOSE. NO RESPONSIBILITY IS ASSUMED FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES, INCLUDING WITHOUT LIMITATION DAMAGES RESULTING FROM MATHEMATICAL INACCURACY OF THE PRODUCT OR LOSS OF STORED DATA. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS OR EXCLUSIONS MAY NOT APPLY TO YOU. This warranty gives you specific rights, and you may also have other rights which vary from state to state.

CASIO, INC.
570 MOUNT PLEASANT AVENUE,
P. O. BOX 7000, DOVER , NEW JERSEY 07801 U.S.A.

LIMITED WARRANTY: ELECTRONIC CASH REGISTER DIVISION

This product, except the battery, is warranted by Casio Canada Limited to the original purchaser to be free from defects in material and workmanship under normal use for a period of six months from the date of purchase. During the warranty period, and upon proof of purchase, the product will be repaired or replaced (with the same or a similar model) at Casio's option, at a Casio Authorized Service Centre without charge for either parts or labour. The terminal resident software and programmable software, if any, included with this product or any programmable software which may be licensed by Casio or one of its authorized dealers, is warranted by Casio to the original licensee for a period of ninety (90) days from the date of license to conform substantially to published specifications and documentation provided it is used with the Casio hardware and software for which it is designed.

For a period of ninety (90) days, upon proof of license, Casio will, at its option, replace defective terminal resident software or programmable software, correct significant program errors, or refund the license fee for such software. Significant program errors will be significant deviations from written documentation or specifications. These are your sole remedies for any breach of warranty. In no event will Casio's liability exceed the license fee, if any, for such software. This warranty will not apply if the product has been misused, abused, or altered.

Without limiting the foregoing, battery leakage, bending of the unit, a broken display tube, and any cracks or breaks in the display will be presumed to have resulted from misuse or abuse. To obtain warranty service you must take or ship the product, freight prepaid, with a copy of the sales receipt or other proof of purchase and the date of purchase, to a Casio Authorized service Centre. Due to the possibility of damage or loss, it is recommended when shipping the product to a Casio Authorized Service Centre that you package the product securely and ship it insured.

CASIO HEREBY EXPRESSLY DISCLAIMS ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING ANY IMPLIED WARRANTIES OF MERCHANTABILITY, MERCHANTABILITY, DURABILITY, OR OF FITNESS FOR A PARTICULAR PURPOSE. NO RESPONSIBILITY IS ASSUMED FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES, FORESEEABLE OR OTHERWISE, INCLUDING, WITHOUT LIMITATION, DAMAGES RESULTING FROM MATHEMATICAL INACCURACY OF THE PRODUCT OR LOSS OF STORED DATA, EVEN IF CAUSED BY THE NEGLIGENCE OF CASIO, ITS EMPLOYEES OR AGENTS, AND NOTWITHSTANDING ANY FUNDAMENTAL BREACH BY CASIO.

This digital apparatus does not exceed the Class A limits for radio noise emissions from digital apparatus as set out in the Radio Interference Regulations of the Canada Department of Communications.

CASIO CANADA
6455 VIPOND DRIVE, MISSISSAUGA, ONTARIO L5T 1J9
FOR THE LOCATION OF THE NEAREST SERVICE CENTRE

Model: Serial Number: Date of Purchase:

Your Name:

Address:

Dealer's Name:

Address:

CASIO®

CASIO COMPUTER CO., LTD
6-1, Nishi-Sinjuku 2-chome
Shinjuku-ku, Tokyo 163-02, Japan

SA9606-A

Printed in Malaysia

PCR-360* INC

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>